

THE FIELD FLOATER

High Capacity Grain Carts



USER MANUAL

To the Purchaser



This is the safety alert symbol. It is used to alert the operator to an instruction concerning the personal safety and risk factor of this equipment. Always observe and heed these very important instructions to promote a safe operation with good preventive maintenance habits.

This new Balzer Inc. product is designed and manufactured to give years of very dependable service when used for the purpose for which it is intended, and when properly maintained.

NEVER OPERATE THIS EQUIPMENT UNTIL USER FULLY UNDERSTANDS THE COMPLETE CONTENTS OF THIS MANUAL. FOR OWNERS WHO DO NOT OPERATE THIS EQUIPMENT, IT IS THE OWNER'S RESPONSIBILITY THAT THE USER IS PROPERLY INSTRUCTED AND IS FULLY AWARE OF THIS MANUAL'S CONTENTS.

This is important in the safe handling of this equipment and promoting an efficient operation. If there are any questions about areas in this manual, it is important to contact your dealer for clarification.

This machine is warranted as stated on the next page. A registration card is to be filled in by your dealer with your name and address, and promptly returned to the factory. The card provides a ready reference to help you in securing warranty and in answering questions that you may have at some later date.

Operating instructions and parts book are shipped with this machine. If parts of this book are missing or become unreadable, contact your dealer for a new set.

The serial number and identification tag is located to the front of the frame. Please refer to these numbers when parts or warranty communication is necessary.

PLEASE FILL IN THE FOLLOWING INFORMATION FOR YOUR RECORDS:

Date of purchase _____

Owner's name _____

Dealer's name _____

Serial # Identification # _____

Warranty



WARRANTY MANUFACTURER

Dealer or Distributor understands and agrees that the Manufacturer extends only the following Warranty to customers. In the event Dealer or Distributor extends any additional warranty (such as by enlarging the scope or period of warranty or undertaking a warranty of merchantability or fitness for any particular purpose) or any other obligation whatsoever, Dealer or Distributor shall: (1) be solely responsible therefore (2) have no recourse against Manufacturer thereof and (3) defend, indemnify and hold Manufacturer harmless against any claim or cause of action whatsoever arising out of, or occasioned by, Dealer or Distributor's extension of said additional warranty or obligation.

CERTIFICATE OF GENERAL EQUIPMENT WARRANTY



Balzer Inc. warrants new Products sold by it to be free from defects in material or workmanship for a period of one (1) year after date of delivery to the first user and subject to the following conditions. Balzer Inc.'s obligation and liability under this Warranty is expressly limited to repairing or replacing at Balzer Inc.'s option, any parts which appear to Balzer Inc. upon inspection to have been defective in material or workmanship. Such parts shall be provided at no cost to user, at the business establishment of the authorized Balzer Inc. dealer or distributor of the Product during regular working hours. This Warranty shall not apply to component parts or accessories of Products not manufactured by Balzer Inc. and which carry the warranty of the manufacturer thereof, or to normal maintenance (such as tune-up) or normal maintenance parts (such as oil filters). Replacement or repair parts installed in this Product covered by this Warranty are warranted only for the remainder of this Warranty as if such parts were original components of said Product. **BALZER INC. MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, AND MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.**

Balzer Inc.'s obligation under this Warranty shall not include any transportation charges, cost of installation, duty taxes or any other charges whatsoever, or any liability for direct, indirect, incidental or consequential damage or delay. If requested by Balzer Inc. products or parts for which a warranty claim is made are to be returned transportation prepaid to Balzer Inc. Any improper use, including operation after discovery of defective or worn parts, operation beyond rated capacity, substitution or parts not approved by Balzer Inc. company or any alteration or repair by others in such manner as in Balzer Inc. company's judgment affects the Products materially and adversely, shall void this Warranty.

“NO EMPLOYEE OR REPRESENTATIVE IS AUTHORIZED TO CHANGE THIS WARRANTY IN ANY WAY OR GRANT ANY OTHER WARRANTY UNLESS SUCH CHANGE IS MADE IN WRITING AND SIGNED BY AN OFFICER OF BALZER INC. AT ITS HOME OFFICE.”

LIABILITY FOR DELAYS

No liability shall attach to Manufacturer direct, or indirect, incidental or consequential damages or expenses due to loss, damage, detention of delay in delivery of Products resulting from acts or delays beyond its control.

TABLE OF CONTENTS

To the Purchaser.....	Inside Front Cover
Warranty.....	Inside Front Cover
Table of Contents.....	Inside front Cover
Section A-Safety.....	Pages 1-9
Section B-Operation.....	Pages 1-12
Section C-Lubrication and Maintenance.....	Pages 1-13
Section D-Troubleshooting.....	Pages 1-7
Section E-Parts Section.....	Pages 1-28

Safety



Section A

Safety



Section A

The following Safety Alert Symbols mean ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED! They stress an attitude of “Heads Up for Safety” and can be found throughout this Operator’s Manual and on the machine itself.

BEFORE YOU ATTEMPT TO OPERATE THIS EQUIPMENT, READ AND STUDY THE FOLLOWING SAFETY INFORMATION. IN ADDITION, MAKE SURE THAT EVERY INDIVIDUAL WHO OPERATES OR WORKS WITH THIS EQUIPMENT, WHETHER FAMILY MEMBER OR EMPLOYEE, IS FAMILIAR WITH THESE SAFETY PRECAUTIONS.

Our Company ALWAYS takes operator safety into consideration when designing its machinery, guards, and exposed moving parts for operator protection. However, some areas can NOT be guarded or shielded in order to assure proper operation. In addition to this Operator’s Manual; decals on the machine warn of further danger and should be read and observed closely.



DANGER “DANGER” indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING “WARNING” indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION “CAUTION” indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. May also alert against unsafe practices.

READ and follow the instructions on all decals.

REMEMBER! It is the owner’s responsibility for communicating information on the safe use and proper maintenance of this machine! This includes providing understandable interpretation of these instructions for operators who are not fluent in reading English.

MANDATORY SAFETY SHUTDOWN PROCEDURE

BEFORE cleaning, adjusting, lubricating or servicing the unit:

1. Remove the ignition key from the power unit engine.
2. Make sure that all movement of the unit has ceased. ONLY when you have taken these precautions can you be sure it is safe to proceed. Failure to follow the above procedure, could lead to death or serious bodily injury.
3. Disconnect the PTO.

ADDITIONAL SAFETY REMINDERS

USER/OPERATOR SAFETY PRACTICES are included in this Operator's Manual and are intended to promote SAFE OPERATION of the unit.

These guidelines do not preclude the use of good judgment, care, and common sense as may be indicated by the particular job site work conditions.

It is essential that operators be physically and mentally free of mind altering drugs and chemicals and thoroughly trained in the safe operation of the unit. Such training should be presented completely to all new operators and not condensed for those claiming previous experience.

Some photographs used in this manual may show Doors, Guards, and Shields open or removed for illustration purposes ONLY. BE SURE that all Doors, Guards, and Shields are in their proper operating positions BEFORE operating the unit. NEVER operate this unit with any guards or shields not in place. Replace any missing or damaged ones.

Keep hands and feet away from all moving parts.

The operator MUST know the capabilities and work applications for the machine, and operate it at speeds slow enough to insure complete control at all times. When working on uneven ground or near the edge of roadbeds, there is no substitute for good judgment and only operators with sufficient experience should attempt such work.

NEVER assume that everybody is as safety conscious as you are.

Safety



Section A

Be alert and avoid loose or soft surface conditions that could cause tipping or loss of control. Avoid side hill travel when possible by driving up or down the slope.

ALWAYS check the job site for terrain hazards, obstructions, and bystanders.

DO NOT allow minors and any unqualified personnel to operate or be near the unit unless properly supervised. NEVER allow anyone to ride on the unit at anytime.

NEVER leave the unit running unattended.

ALWAYS wear appropriate personal safety gear as called for by the job or working conditions! NEVER wear loose clothing while working around moving parts.

ALWAYS be aware of pinch point areas on the unit.

Before loading, make sure that the unit does not have any foreign objects or material in it that can cause equipment damage or personal injury.

Safety grates inside box protect users from accidental contact with augers and help prevent possible suffocation from grain. Never operate this equipment with these grates missing. Rotating augers can cause serious injury or death!

The max speed of the towing tractor is 25 mph. Be sure the rear of the unit has a clean SMV emblem properly displayed if towing at less than 25 MPH on any public roadway. At night, proper warning and running lights are necessary as required by state law. Improper electrical connection between the tow vehicle and the trailer will result in inoperable lights and electric brakes, and can lead to collision. Before each tow:

- Check that the taillights, brake lights and turn signals work.
- Check that the electric brakes work by operating the brake controller inside the tow vehicle.

Stopping distance increases with speed and weight of towed loads, and on slopes. Towed loads with or without brakes that are too heavy for the tractor or are towed too fast can cause loss of control. Consider the total weight

Safety



Section A

Observe these recommended maximum road speeds, or local speed limits which may be lower.

The tractor must be heavy and powerful enough with adequate braking power for the towed load. Use additional caution when towing loads under adverse surface conditions, when turning, and on inclines.

DO NOT exceed the maximum weight carrying capacity of the grain cart or the tractor manufacturers maximum towing capacity; whichever is lower.

ALWAYS use a hitch pin that has a safety clip pin.

DO NOT smoke while working on hydraulic systems!

NEVER use your hands to search for hydraulic fluid leaks; escaping fluid under pressure can be invisible and can penetrate the skin and cause a serious injury! If any fluid is injected into your skin, see a doctor at once! Injected fluid MUST BE surgically removed by a doctor familiar with this type of injury or gangrene may result!

DO NOT attempt to loosen or disconnect ANY Hydraulic Lines, Hoses, or Fittings without first relieving hydraulic circuit pressure. Also, be careful NOT to touch any hydraulic components that have been in recent operation because they can be extremely HOT!

Always move cart with a farm tractor only. The max speed anytime is 25 mph.

SAFETY SIGNS ARE IMPORTANT

Safety signs or decals provide very important information and instructions designed to alert you to dangers and hazards that can be present during operation of this equipment. However, safety sign instructions must be read, understood and followed to be effective.

REPLACEMENT OF SAFETY SIGNS

Safety signs or decals must be kept clean and readable. If they become unreadable for any reason, they must be replaced with an identical replacement decal. Safety decals must also be replaced if parts are repaired or replaced with new parts that do not already include the necessary safety decals.

APPLICATION OF SAFETY DECALS

Surface preparation is very important for safety decals to properly adhere. Grease, oil and dirt must be removed and the surface must be smooth and dry. Most decals have a split backing which is meant to be removed from the split outward. To apply the decals, follow these procedures:

1. Position the decal in the proper location and hold firmly over the largest portion of the backing.
2. Use one hand to hold the decal in position, with the other hand, carefully roll the loose end over and peel the backing outward. When the backing is removed as described and shown (Fig. 1), with even and gradual pulling, the decal will roll onto the surface smooth and wrinkle free.
3. With the smallest portion of the decal attached, the same procedure can be applied to the other half.
4. When the decal has been attached in place, use a cloth or soft paper towel to burnish the decal onto the cleaned surface. Work gently from the middle outwards to avoid creating any wrinkles.

REPLACEMENT DECALS

Order replacement decals by part number through your nearest dealer. Part numbers are printed on each decal.



Fig. 1



90295



OPERATION INSTRUCTIONS

PRE OPERATION CHECK

- MAKE SURE ALL SAFETY SHIELDS ARE IN PLACE.
- MAKE SURE THERE IS NO FROZEN MATERIAL TO OBSTRUCT THE GRAIN DOORS OR AUGERS.
- MAKE SURE TRACTOR DRAW BAR MATCHES STANDARDS SHOWN IN DRAWBAR ADJUSTMENT DECAL.

ATTACHING TO TRACTOR

- ATTACH TRACTOR DRAWBAR TO AUGER CART HITCH WITH PROPERLY SIZED HITCH PIN THAT HAS A RETAINER DEVICE.
- CRANK TRAILER JACK TO SLOWLY PLACE PRESSURE ON DRAWBAR. RETRACT JACK FULLY TO PROVIDE MAXIMUM GROUND CLEARANCE.
- CHECK THAT TRACTOR AND PTO HAVE PROPER SIZE BUSHES. CHECK THAT PTO SLIDES FREELY AND IS NOT DAMAGED. ATTACH PTO SHUNT TO TRACTOR SECURELY AS REQUIRED BY ITS LOCKING MECHANISM. PTO SHOULD HAVE APPROXIMATELY 1/3 OVER LAP.
- ATTACH HYDRAULIC LINES MAKING SURE THE CONNECTORS ARE CLEAN AND IN GOOD REPAIR.

HOSE COLOR MARKINGS

RED - BRAKE CYLINDERS
 YELLOW - STEERING LOCK-OUT
 BLUE - GRAIN DOORS
 GREEN - CLEAN-OUT DOORS
 ORANGE - AUGER FOLDING

INITIAL START-UP

- NEVER OPERATE THIS MACHINE IF SHIELDS ARE MISSING OR IF PERSONS ARE IN OR ON THIS MACHINE. DO NOT LEAVE TRACTOR SEAT. KEEP EVERYONE AWAY WHILE OPERATING THIS MACHINE.
- OPERATE ALL HYDRAULIC CONTROLS TO BECOME FAMILIAR WITH THE FUNCTION OF EACH TRACTOR LEVER AND TO VISUALLY SEE THAT THE AUGER CART IS RESPONDING CORRECTLY.
- ENGAGE PTO SLOWLY WITH TRACTOR THROTTLE AT FAST IDLE. WATCH AND LISTEN TO CONFIRM THAT THE AUGER CART IS OPERATING PROPERLY. RUN AT FAST IDLE FOR 5 MINUTES. DISENGAGE PTO AND SHUT OFF TRACTOR ENGINE AND REMOVE KEYS FROM IGNITION. MAKE ALL ADJUSTMENTS BEFORE ANY FURTHER OPERATING IS ATTEMPTED.

IN FIELD PROCEDURES

- ALWAYS CLOSE GRAIN DOORS BEFORE DISENGAGING PTO AND ALWAYS ENGAGE PTO BEFORE OPENING GRAIN DOORS.
- BE SURE GRAIN DOORS ARE CLOSED BEFORE LOADING.
- ALWAYS ENGAGE STEERING LOCK-OUT CYLINDERS BEFORE ATTEMPTING TO BACK-UP THIS AUGER CART.

90289



DANGER

MOVING PARTS HAZARD

- Keep hands, clothing, and hair away from moving belts and parts.
- Replace guard before operating.

21730



90175


Grease all steering systems

The king pin requires grease every day the unit is used in the field.

Grease sufficiently two places on the top and bottom of king pin, position tires all right, then all left, and center to distribute grease around the king pin.

Grease well after washing the unit and at the end of the season.

Grease abundantly the tandem axle cross main tube every day.



37601

IMPORTANT

HUB BEARING ADJUSTMENT

1. DELIVERY
2. FIRST DAYS USE
3. WEEKLY

UNTIL NO END PLAY CAN BE DETECTED

4. SEMIANNUALLY

#17546

17546



90243



WARNING

TO PREVENT SERIOUS INJURY OR DEATH

- READ AND UNDERSTAND THE OPERATOR INSTRUCTIONS BEFORE OPERATING OR SERVICING THIS MACHINE. FAMILIARIZE YOURSELF WITH ALL CONTROLS, SAFETY FEATURES AND SERVICE PROCEDURES. REVIEW SAFETY PRECAUTIONS MANUALLY.
- NEVER ALLOW ANYONE TO PLAY ON OR AROUND THIS MACHINE WHILE OPERATING OR SERVICING.
- SECURELY ATTACH MACHINE TO TOWING UNIT. USE A HIGH STRENGTH APPROPRIATELY SIZED HITCH PIN WITH A MECHANICAL RETAINER AND STITCH SAFETY CHAIN.
- DO NOT EXCEED 5 MPH WHEN LOADED.
- NEVER ENTER GRAIN TANK WHILE IN OPERATION. FLOWING GRAIN TRAPS AND SUFFOCATES VICTIMS IN SECONDS.
- BEFORE TRANSPORTING ON PUBLIC ROADWAYS, BE SURE ALL LIGHTS, REFLECTORS AND SPRAY ARE IN PLACE AND IN WORKING ORDER.
- BEFORE MAINTENANCE OR REPAIR, STOP VEHICLE, SET PARKING BRAKE AND REMOVE IGNITION KEY.
- DO NOT DRINK AND DRIVE.

90178

CAUTION


THIS AUGER CART IS DESIGNED AND SOLD FOR ON FARM-IN FIELD USE ONLY.

IT IS NOT FOR USE ON PUBLIC ROADWAYS EXCEPT AS INCIDENTAL TO FARM USE. BECAUSE OF LOAD CAPACITIES ON BRIDGES AND PONDS THE AUGER CART IS NOT INTENDED FOR HAULING LOADS ON PUBLIC ROADWAYS. IT IS THE RESPONSIBILITY OF THE OPERATOR OF THE AUGER CART TO HEED ALL FEDERAL, STATE, PROVINCIAL AND LOCAL REGULATIONS WITH RESPECT TO WEIGHT LIMITATION ON PUBLIC ROADS AND BRIDGES.

WHEN TRANSPORTING AN EMPTY AUGER CART ON PUBLIC ROADWAYS OBSERVE ALL FEDERAL, STATE, PROVINCIAL AND LOCAL REGULATIONS CONCERNING LIGHTS AND OTHER WARNING DEVICES. A SLOW MOVING VEHICLE SIGN BRACKET IS PROVIDED AT THE REAR OF THE AUGER CART. IT IS RECOMMENDED THAT YOU INSTALL AN SLOW MOVING BEFORE TRANSPORTING THE AUGER CART DOWN PUBLIC ROADWAYS.

90177

DANGER



USE EXTREME CAUTION WHEN PASSING UNDER LOW HANGING POWER LINES. SERIOUS INJURY OR DEATH FROM ELECTROCUTION MAY RESULT.

ALWAYS KEEP AUGER IN TRANSPORT POSITION WHEN NOT IN USE.

DO NOT ATTEMPT TO FREE EQUIPMENT FROM POWER LINES. CONTACT YOUR POWER COMPANY. STAY AWAY FROM AUGER AND ALL ATTACHED EQUIPMENT.

90173

WARNING

DO NOT ALLOW CHILDREN TO PLAY ON OR AROUND THIS AUGER CART. FLOWING GRAIN CAN TRAP AND SUFFOCATE A VICTIM IN SECONDS.

90179



WARNING



HYDRAULIC SYSTEM CONTAINS HOT OIL UNDER PRESSURE WHICH CAN PENETRATE SKIN CAUSING SERIOUS INJURY, BURNS OR SLAUGHTERS.

IF HYDRAULIC FLUID COMES IN CONTACT WITH SKIN, WASH THE CONTAMINATED AREA WITH SOAP & WATER IMMEDIATELY IF SKIN HAS BEEN PUNCTURED.

ALWAYS KEEP FITTINGS TIGHT AND REPLACE NEW WIPES ON DAMAGED HOSES. RELEASE PRESSURE AND ALLOW OIL TO COOL BEFORE LOOSENING FITTINGS.

90172

WARNING

TOW ONLY WITH FARM TRACTOR

90244

IMPORTANT

PRE SEASON CHECKLIST

- MAKE SURE ALL SAFETY SHIELDS ARE IN PLACE.
- REPAIR AND ADJUST WHEEL BEARINGS.
- TORQUE LUG NUTS TO 400 FT.LBS.
- CHECK TIRES FOR CRACKS AND WEAR. INFLATE TO RECOMMENDED PRESSURE PER OPERATORS MANUAL.
- LUBRICATE ALL GREASE FITTINGS PER OPERATORS MANUAL.
- DRAIN AND REFILL GEARBOX WITH SAE 80-90 GEAR OIL.
- INSPECT ALL HYDRAULIC LINES AND FITTINGS FOR ABRASIONS, CUTS OR LEAKS. REPAIR OR REPLACE IF NECESSARY.
- INSPECT ALL BEARINGS FOR SEAL FAILURE OR WEAR. REPLACE IF NECESSARY.
- OPERATE MACHINE AT SLOW SPEED FOR SEVERAL MINUTES AND OBSERVE FOR UNUSUAL NOISES OR OPERATION. CHECK ALL TRACTOR AND CHECK FOR OVERHEATED BEARINGS.
- TIGHTEN OR REPLACE LOOSE, WORN OR BROKEN BOLTS OR CONNECTORS.
- MAKE SURE ALL SAFETY AND OPERATIONAL DECALS ARE IN PLACE AND LEGIBLE.

DAILY SEASON CHECKLIST

- LUBRICATE PER OPERATORS MANUAL.
- CHECK TIRE INFLATION.
- INSPECT HYDRAULIC SYSTEM FOR LEAKS AND PROPER OPERATION.
- INSPECT EQUIPMENT FOR UNUSUAL NOISES WHILE IN OPERATION.
- INSPECT ALL CONNECTIONS. REPLACE ALL LOOSE, WORN OR BROKEN BOLTS.
- INSPECT WHEEL LUG NUTS AND TORQUE TO 400 FT.LBS.

AFTER SEASON CHECKLIST

- CLEAN OUT ALL ACCUMULATED GRAIN FROM BOX AND AUGER ASSY.
- LEAVE AUGER INTAKE AND CLEAN-OUT DOORS IN OPEN POSITION DURING STORAGE TO PREVENT MOISTURE ACCUMULATION.
- CLEAN OFF ALL ACCUMULATION OF DIRT AND CHAFF TO PREVENT MOISTURE RETENTION AND MUSTY OR WORN OFF.
- REPAIR ALL AREAS WHERE PAINT HAS CHIPPED OR WORN OFF.
- ALWAYS STORE WITH AUGER IN DOWN POSITION.

90176

WARNING



KEEP HANDS CLEAR

ENTANGLEMENT IN ROTATING AUGER CAN CAUSE SERIOUS INJURY.

ALWAYS SHUT OFF POWER BEFORE ATTEMPTING TO SERVICE AUGER.

90174

WARNING

WINDOWS PROVIDE A LIMITED VIEW OF PERSONS OR TRAFFIC APPROACHING FROM THE REAR OF AUGER CART.

BE ABSOLUTELY SURE OF WHAT IS BEHIND BEFORE TURNING STOPPING OR BACKING.

90242

Operation



Section B

Operation



Section B

PRE OPERATION CHECK

- Make sure all safety shields are in place.
- Make sure that there is no frozen or foreign material obstructing the grain doors or augers.
- Make sure the tractor draw bar matches the standards shown in the draw bar adjustment diagram.

HOSE COLOR MARKINGS

RED—Brake Cylinders
YELLOW—Steering Lock-Out
BLUE—Grain Doors
GREEN—Clean-Out Doors
ORANGE—Auger Folding
NO COLOR—Clutch


DRAW-BAR ADJUSTMENT

PTO STYLE	DIM "A"
1 3/8" - 21 SPLINE	16"
1 3/4" - 20 SPLINE	20"

If these dimensions are not possible on your tractor, contact your Balzer dealer.

ATTACHING TO TRACTOR

- Attach the tractor draw bar to the auger cart hitch with a properly sized hitch pin that has a retainer device.
- Crank the trailer jack to slowly place pressure on draw bar. Move jack to storage location and secure.
- Check that the tractor and PTO have the proper size splines. Check that the PTO slides freely and is not damaged. Attach the PTO shaft to the tractor securely, as required by its locking mechanism. PTO should have approximately 1/3 over-lap.
- Attach the hydraulic lines, making sure that the connectors are clean and in good repair. See the hose color list above.



NOTE!

To prevent premature driveline failures, tractor turning should be limited to approximately 10 degrees when drive line is rotating

INITIAL START-UP

- Never operate this machine if any shields are missing or if persons are in or on this machine. Do not leave the tractor seat. Keep everyone away while operating this machine.
- Operate all of the hydraulic controls to become familiar with the function of each tractor lever and to visually see that the auger cart is responding correctly.
- Engage the PTO slowly with the tractor throttle at idle.
- The PTO has 1 3/8 –21 or 1 3/4—20 tractor ends and 1 3/4—20 implement ends. The implement end provides a friction clutch or shear bolt that protects the gear box and drive from overload. The PTO must be engaged slowly, use max modulation on tractor. Do not slam engage!
- Watch and listen to confirm that the auger cart is operating properly. Run at fast idle for five (5) minutes, disengage the PTO, shut off the tractor engine and remove the keys from the ignition. Make all adjustments before any further operating is attempted.



NOTE!

Make mental and/or physical notes concerning which way to move the lever to get the desired result!

IN FIELD PROCEDURE

- Always close the grain doors before disengaging the PTO and always engage the PTO before opening the grain doors.
- Be sure the grain doors are closed before loading.
- Always engage the steering lock-out cylinders before attempting to back up this auger cart.
- Always load Grain Cart evenly from front to back to avoid excessive tongue overload.




DANGER! Never Operate without PTO Guards!

Operation—PTO/JACK PTO

The PTO has 1 3/8 –21 or 1 3/4—20 tractor ends and 1 3/4—20 implement ends. The implement end provides a friction clutch or shear bolt that protects the gear box and drive from overload. The PTO must be engaged slowly, use max modulation on tractor. Do not slam engage!

Jack Storage

The jack storage location is pictured below. This location keeps it out of the way of the tires and removes the possibility of dragging.



Shear Bolt



Jack Storage

Vertical Auger

The hydraulic hoses with orange band control the vertical auger folding.



CAUTION

Never transport with vertical auger in unloading position. Doing so may cause structural damage to the vertical auger and grain cart.

Operation



Section B

Operation—Clean-Out

Front Clean-Out Door


These doors are available for clean-out when needed.



DANGER!

Never open for clean-out until and unless all movement has stopped and the equipment is completely shut down. Do not remove or distort safety bars.

Bottom Clean-Out Door Operation—Grain Doors



Grain Doors, Hydraulic Control

The two hydraulic hoses with the blue markings control the grain doors.

These doors are the primary means of starting, stopping and regulating grain flow to the horizontal auger. For most common grains, the doors do not need to be completely open for full capacity discharge.



DANGER!

Keep all shields in place at all times.



Operation—Steering Steering System

The hydraulic hose marked with the yellow band must be connected to a hydraulic outlet that has a float position. The hydraulic lever must be in the float position for the steering to function. Moving the lever into a position that forces oil through the hose will lock the wheels straight for backing up. The steering cylinders have two internal functions, locking the wheels straight for backing is one function and was discussed earlier. The second function is the steering. This part of the steering cylinders is connected by hydraulic hoses from one cylinder to the other, and is self contained. As one wheel turns, oil is moved through the hoses to create an identical movement in the other wheel's cylinder. The system hoses must be full of oil and no air. If oil is lost or air enters the system, it must be bled. See the next page for the proper bleeding procedure.



NOTE

Make mental and/or physical notes concerning which way to move the lever to get the desired result!



LOCK OUT FOR
BACKING

STEERING
FUNCTION

Operation



Section B

Bleeding Procedure And Alignment For Tandem And Tridem Steering

Air in the system is the major cause for wheel misalignment. If the tires do not follow in parallel during forward travel, follow the steps outlined below. Have someone assist with this procedure, for both ease and safety.

THIS IS AN EXCELLENT TIME TO GREASE KINGPINS COMPLETELY

1. Lock the steering straight.

A single hydraulic hose is provided to connect to a free outlet at the tractor. This line supplies hydraulic pressure to a portion of the steering cylinder which forces the wheels to steer straight. Once the wheels are completely straight, the tractor lever must be put into neutral position to hold pressure in the line.

2. Jack axles or arms up until steering wheels are just off the ground.

Both steering tires must be off the ground, for tridems, do one axle at a time. Be extremely careful while jacking; use a bottle jack rated for at least 2 tons on each wheel. Use proper blocking and choose appropriate locations for jack placement.


3. Connect steering distributor to tractor hydraulics.

If the equipment has brakes, a service port is provided close to the tee at the center between the brake hoses. If there are no brakes, a separate hose must be used to supply hydraulic pressure. Jumper hose p/n 37524 should be hooked either to the service port, if available, or to a temporary separate hose to a hydraulic outlet at the tractor. Connect the other end of the jumper hose to the steering distributor center port which is in line with the hose that runs to the middle port on the steering cylinder.



NOTE!

Do not open petcocks unless bleeding the system. Opening petcocks can allow air to enter the system, which will cause improper steering action.



Hose connection on steering distributor

4. Applying pressure.

Apply hydraulic pressure through either the brake system or through the temporary hose. After pressure is applied, open the bleeder valve in the line with the middle port on both steering cylinders. When no more oil or air is escaping, close the bleeder valve and open the other bleeder valve at the rod end of the cylinder. This last procedure will allow the steering completely. Close the rod end bleeder on both steering cylinders. Move the tractor lever controlling flow to the service port into neutral position.

5. Change the connection from tractor hydraulics to steering distributor.

Disconnect the jumper hose from the steering distributor and connect it to the port just above the previous location.

6. Applying pressure.

Engage the tractor lever controlling the flow to the hose connected to the service port in order to provide pressure to the new location on the steering distributor. Open the rod end bleeder valve on each steering cylinder until no air is escaping and re-close. Open the middle bleeder valve, this will cause the steering cylinders to retract and the tires to return to parallel and inline with the other tires. When movement stops, close the bleeder valve, hold pressure for 20 seconds and then move tractor lever to neutral position.

7. Change the connection from tractor hydraulics to steering distributor.

Disconnect the jumper hose from the steering distributor and connect it to the port just below the previous location.

Operation



Section B

8. Hold the pressure.

Engage the tractor lever controlling the flow to the hose connected to the service port in order to provide pressure to the new location on the steering distributor. Hold the pressure for 20 seconds and then move tractor lever into neutral position. Remove jumper hose from steering distributor.




NOTE!

TRIDEM UNIT— PERFORM THIS PROCEDURE ON REMAINING AXLE.

9. Final alignment.

The toe on all steering axles should be adjusted to maintain 1/8" toe-in at a distance of 18 inches from the axle center. The cylinder rod end is threaded to the clevis for adjustment. Both tandem and tridem equipment should have the same toe-in. After proper toe-in has been achieved, the jacks can be lowered and the jacks and blocks removed.



Horizontal Auger Shut-Off Clutch

SEQUENCE OF CLUTCH OPERATION

1. Use the clutch to disengage the Horizontal Auger and run only the vertical auger for 3 to 5 seconds.
2. Engage the Horizontal Auger—now all augers are running.

REPEAT THE SEQUENCE AT EVERY START-UP



NOTE!

The hydraulic hose that controls the clutch is a 3/8" hose and has no color marking.



NOTE!

Make mental and/or physical notes concerning which way to move the lever to get the desired result!



WARNING!

This clutch will not tolerate more than 2500 PSI oil pressure. If your tractor relief is set higher, it must be reduced or you will need to add a relief valve to the system. Contact Balzer for information on acquiring this valve and proper installation.




Lubrication & Maintenance



Section C

PTO Lubrication Specifications



LUBRICATE ALL FITTINGS WITH A GOOD QUALITY LITHIUM SOAP BASE E.P. GREASE MEETING THE N.L.G.I. #2 SPECIFICATIONS AND CONTAINING NO MORE THAN 1% MOLYBDENUM DISULFIDE. (EX. SHELL SUPER DUTY OR EQUIVALENT)

AN E.P. GREASE MEETING THE N.L.G.I. #2 SPECIFICATIONS AND CONTAINING 3% MOLYBDENUM DISULFIDE MAY BE SUBSTITUTED IN THE TELESOPING MEMBERS ONLY. (EX. MOBIL OIL COMPANY, "MOBILGREASE COMPANY", SHELL OIL COMPANY, "RETINAX AM". TEXACO, "MOLYTEX EP #0 AND #2".)

GREASE RECOMMENDATIONS


<u>INTERVAL</u>	<u>LOCATION</u>	<u>AMOUNT</u>
8 HRS.**	CROSS & BEARINGS	1 PUMP
8 HRS.**	TELESOPING MEMBERS	4-8 PUMPS

** CONSTANT ANGLE APPLICATIONS MUST HAVE A LUBE INTERVAL OF 4 HOURS.

CAUTION!! REPLACEMENT PARTS ARE NOT LUBRICATED
REPLACEMENT PARTS MUST BE LUBRICATED AT TIME OF ASSEMBLY.
USE AMOUNT LISTED ABOVE PER LOCATION THEN FOLLOW LUBE RECOMMENDATIONS OUTLINED ABOVE FOR LUBING INTERVALS.

Lubrication—Chain Oiler

The oil reservoir to lubricate both drive chains holds about 1 gallon of fluid. Use a good lubricating oil that flows easily. To determine the amount of oil flow, it is best to unscrew one or both lines and visually see the oil flow. Frequency of lubrication should be based on current field conditions. Duration of lubrication should be based on volume of oil flowing through hoses. Under normal field and weather conditions, the chains should be lubricated with approximately 1 ounce of oil every 4 loads.



Lubrication & Maintenance




Section C

Lubrication—Steering

There are 4 grease fittings located in 2 positions on each of the tandem arms; two at the top and two at the bottom of the round center pivot tube.

Grease each location of both arms until new grease can be seen being pushed out.

Greasing should be done daily, at a minimum, and more often as conditions warrant



Grease fittings are located at the top and bottom of the steering hinge kingpins.

To grease the hinge kingpins, it is best to have the wheels steering straight one time, to the left the next time and finally to the right. This process insures that grease is getting to all areas of the kingpin. Proper steering is dependant upon adequate greasing.

When conditions are dry and dusty, the tandem arms and kingpins will require grease more often.



NOTE!

Grease thoroughly before pressure washing near kingpins.

Informational and instructional decals are located above the axle on both sides of the trailer frame. These provide information that must be heeded for safe, trouble free operation.



Lubrication & Maintenance



Section C

Hub:

Check and pack wheel hub bearings seasonally.



Hitch:

A grease fitting is located on top of the hitch. This should be greased every day under normal conditions.



Lubrication—Horizontal Auger

The bearing at the front end of the horizontal auger has a grease line and fitting that permits greasing externally. This location should get 1 to 2 careful pumps of grease every day of constant use.





NOTE!

Excessive pressure while applying grease can be harmful to the bearing seals.

The middle bearing for the horizontal auger has a grease line and fitting that permits greasing externally. This location should get a liberal greasing after every 3 hours of constant use in normal conditions. In dusty or dry conditions, more frequent greasing is recommended.

The bearing at the rear end of the horizontal auger. This location should get 1 to 2 careful pumps of grease every 2 days of constant use.



Lubrication & Maintenance



Section C

Lubrication—Vertical Auger

Three (3) grease fittings are located on the auger folding hinge. These should be greased every day. Pump grease until old grease is visible.

The bearing located at the end of the vertical auger should get 1 to 2 careful pumps of grease every day of constant use.

The mid bearing on the vertical auger has a grease fitting that is accessible with the auger folded. Grease at this location liberally every day of operation under normal conditions and more frequently if dusty or hot.

The bearing at the bottom end of the vertical auger has a grease line and fitting that permits greasing externally. This location should get 1 to 2 careful pumps of grease every day of constant use.



NOTE!

Excessive pressure while applying grease can be harmful to the bearing seals.

Lubrication & Maintenance



Section C

Maintenance—Tire Air Pressure

Balzer Suggested Maximum Allowable Tire Pressure.

TIRE SIZE	PSI
18.4 x 46-12 ply	26
28L-26 R3-12 ply	26
30.5L-32 R3-12 ply	33
850/50-30.5-8 ply	40




WARNING!

Torque lug nuts to 420 ft./lbs.
Tighten lug nuts before each day's use for the first 5 days.



Friction clutch

K96-K96/4




Assembly/Dismantling instructions



NOTE!

Proper Operation of the friction clutch on this machine requires it to be set at its highest position.



The torque setting can be modified with the aid of a setting ring and two alternative location slots in the clutch housing.

1. The setting ring provides for a **min.** position and a **max.** position.

2. The clutch housing incorporates two locating positions for the setting ring (1 and 2) which are situated at different levels.

For each power pack **four** torque settings are possible (see table).

The setting ring can only be removed in relieved condition which is obtained by tightening the nuts.

Dismantling



1. If so equipped - remove the OD locking collars from the hub.



2. To begin dismantling - mount clutch in a vise and tighten down the 6 nuts in even sequence until the spring pack assembly is loose.



3. Remove the setting ring using a flat blade screwdriver.



4. Lift the spring pack assembly out by tilting it up opposite the locating tab which is on the bottom plate of the spring pack.
NOTE: This tab is located to the narrow slot.



5. Remove flange hub together with friction disks and drive plates. Tilt hub as illustrated and lift out.

Assembly



1. Fit friction disks and drive plates to flange hub in correct sequence as illustrated. One friction disk is mounted in the bottom of the clutch housing along with the fiber hub pilot bearing.



2. Insert the flange hub with friction disks and drive plates into the clutch housing - lining up the tabs of the drive plate.



3. Replace spring pack assembly.



4. Replace setting ring to proper location. Noting position window and setting ring to min./max. location.




5. Back off the 6 nuts to the end of the studs. In this position the spring pack is at the pressure controlled by the location of the setting ring.

Friction clutch K96-K96/4

(K96/4 Illustrated Below)

(For K96 having two friction disks: items 4 and 5 are not used and only two of item 3.)



1 Setting ring	5 Drive plate
2 Spring pack assembly	6 Flange hub
3 Friction disk	7 Hug bearing ring
4 Driven plate	8 Clutch housing

Torque setting:

Please take instructions at page 4 into account.

Troubleshooting



Section D

Troubleshooting



Section D

1) Trouble with steering of rear axles on tandem or front and rear of tridem models.

A) Ensure the hydraulic line for the steering (yellow color) is in the right side of the tractor's hydraulic bank.

B) Grease the kingpin assemblies two (2) grease fittings on both sides in the straight position and in the turned position. This kingpin assembly must be greased daily in order for the steering system to function properly.

C) System may have air trapped inside resulting in a malfunction. This requires the hydraulic steering system to be bled. See Steering System bleeding instructions.

D) If the system is still not steering properly, call Balzer's service department at 800-795-8551 Extension 134 or 0 for the operator.

2) Automatic chain oiler doesn't appear to let oil drain.

A) Unscrew the cap of the oil reservoir and then open the valve.

B) If this doesn't work, call Balzer's service department at 800-795-8551 Extension 134 or 0 for the operator.

3) Trouble figuring out which hydraulic hoses go where.

A) RED marked hose = Brake Cylinders (Note: if option is available on your cart.)

B) YELLOW marked hose = Steering System

C) BLUE marked hose = Inside Grain Doors

D) GREEN marked hose = Underside Clean-out Doors

E) ORANGE marked hose = Unload Auger Fold

Troubleshooting



Section D

4) Unload auger has abnormal vibration.

- A) Ensure the hydraulic fold is extended to the full stroke position. This is needed in order to lock the two halves together.
- B) May require the clevis on the high end of the hydraulic cylinder to be adjusted to ensure the system is being locked when the cylinder is in the full stroke position.
- C) Ensure the drive train tensioner has been properly adjusted to take the slack out of the chain.



NOTE!

Grain Door Timing

In most cases, each time the grain doors are closed, they will re-open evenly. If this is not occurring and is considered a problem contact Balzer for information and help solving the situation.

5) Trouble backing up with steering wheels going in the wrong direction (Note: This may occur in extreme conditions such as mud, ice and/or snow.)


- A) Take the hydraulic line out of the float position and then move the lever to pressurize the cylinders. This will straighten the tires and then lock them.
- B) System is still not steering properly, call Balzer's service department at 800-795-8551 Extension 134 or 0 for the operator.

SIMPLIFIED HYDRAULIC CIRCUIT FOR TANDEM STEERING


VALVE IN FLOAT POSITION TO STEER

TO TRACTOR VALVE

PRESSURE TO CENTER REAR TIRES TO BACK UP ONLY




SIMPLIFIED HYDRAULIC CIRCUIT FOR TRIDEM CARTS




Vertical Drive Service Information

For Horizontal Auger
Adjust chain tightener
so that in tightest position
there is a 1/2" deflection on
the tight side of chain.



INSTALL IDLER ON THE
TOP OF THE CHAIN




Direction

TIGHT SIDE OF CHAIN

Adjust chain tightener
so that in tightest position
there is a 1/2" deflection on
the tight side of chain.

DETAIL H
SCALE 1 : 8



Parts




Section E

Parts




Section E

GRAINCART 1 3/8-1000 RPM SLIP CLUTCH PTO, PART# 25704



ITEM	PART#	QTY	DESCRIPTION	ITEM	PART#	QTY	DESCRIPTION
1	17479	1	YOKE 1 3/8- 21SPL	11	50641	1	INN. SHIELD TUBE ROUND
2	17157	2	CROSS & BEARING KIT	12	16814	2	BEARING RING SC25
3	17158	2	SPRING PIN 10x90	13	16815	1	SAFETY CHAIN
4	17159	1	INBOARD YOKE S4	14	16818	2	SCREW- IN ITEM 9 & 19
5	50638	1	INBOARD PROFILE S4	15	16816	1	DECAL OUT. FOR ITEM 10
6	50639	1	PROFILE & SLEEVE	16	16817	1	DECAL INN. FOR ITEM 6
7	17162	1	INBOARD YOKE S5	17	17171	1	SUPPORT BEARING
8	50606	1	FRICTION/OVERRUNNING CLUTCH	18	16820	1	ZERK IN ITEM 6
9	17163	1	SHIELD CONE 7-RIB	19	50454	1	SHIELD CONE, 6 RIB
10	50640	1	OUT. SHIELD TUBE OVAL	20	17172	1	LOCK COLLAR KIT ON ITEM 1


GRAINCART 1 3/4-1000 RPM SLIP CLUTCH PTO, PART# 25705



ITEM	PART#	QTY	DESCRIPTION	ITEM	PART#	QTY	DESCRIPTION
1	17200	1	YOKE 1 3/4- 20SPL	11	50641	1	INN. SHIELD TUBE ROUND
2	17157	2	CROSS & BEARING KIT	12	16814	2	BEARING RING SC25
3	17158	2	SPRING PIN 10x90	13	16815	1	SAFETY CHAIN
4	17159	1	INBOARD YOKE S4	14	16818	2	SCREW- IN ITEM 9 & 19
5	50638	1	INBOARD PROFILE S4	15	16816	1	DECAL OUT. FOR ITEM 10
6	50639	1	PROFILE & SLEEVE	16	16817	1	DECAL INN. FOR ITEM 6
7	17162	1	INBOARD YOKE S5	17	17171	1	SUPPORT BEARING
8	50606	1	FRICTION/OVERRUNNING CLUTCH	18	16820	1	ZERK IN ITEM 6
9	17163	1	SHIELD CONE 7-RIB	19	50454	1	SHIELD CONE, 6 RIB
10	50640	1	OUT. SHIELD TUBE OVAL	20	17173	1	LOCK COLLAR KIT ON ITEM 1

Section E


GRAIN CART FRICTION CLUTCH, PART NUMBER 50606



ITEM#	PART#	QTY	DESCRIPTION	ITEM#	PART#	QTY	DESCRIPTION
1	50470	1	CLUTCH HOUSING WITH YOKE	10	50479	1	SUPPORT RING
2	50471	1	WEAR RING	11	50480	1	SEAL RING
3	50472	4	FRICTION DISC	12	50481	1	DRIVE PLATE
4	50473	1	OVERRUNNING HOUSING	13	50482	1	DRIVE PLATE
5	50474	2	RETAINING RING	14	50483	1	SPRING PACK
6	50475	1	SUPPORT RING	15	50484	1	SETTING RING
7	50476	1	HUB	16	50485	2	BOLT HEX, 16mm x 110mm
8	50477	2	DRIVE KEY	17	3149	2	TOPLOCK NUT, HEX HD 16mm
9	50478	2	LEAF SPRING	18	50486	1	CLAMP BRIDGE


2/8/05

GRAINCART 1 3/8-1000 RPM SHEAR YOKE PTO, PART# _____




ITEM	PART#	QTY	DESCRIPTION	ITEM	PART#	QTY	DESCRIPTION
1	17149	1	YOKE 1 3/8- 21SPL	12	16814	2	BEARING RING SC25
2	17157	2	CROSS & BEARING KIT	13	16815	1	SAFETY CHAIN
3	17158	2	SPRING PIN 10x90	14	16818	2	SCREW- IN ITEM 9 & 19
4	17159	1	INBOARD YOKE S4	15	16816	1	DECAL OUT. FOR ITEM 10
5	50638	1	INBOARD PROFILE S4	16	16817	1	DECAL INN. FOR ITEM 6
6	50639	1	PROFILE & SLEEVE	17	17171	1	SUPPORT BEARING
7	17162	1	INBOARD YOKE S5	18	16820	1	ZERK IN ITEM 6
8	50642	1	SHEARBOLT/OVERRUNNING CLUTCH	19	3048	1	BOLT 12mm x 60mm IN ITEM 8
9	17163	2	SHIELD CONE 7-RIB	20	17181	1	NUT 12mm - IN ITEM 8
10	50640	1	OUT. SHIELD TUBE OVAL	21	17172	1	LOCK COLLAR KIT ON ITE
11	50641	1	INN. SHIELD TUBE ROUND				

GRAINCART 1 3/4-1000 RPM SHEAR YOKE PTO, PART# 91409





ITEM	PART#	QTY	DESCRIPTION	ITEM	PART#	QTY	DESCRIPTION
1	17200	1	YOKE 1 3/4- 20SPL	12	16814	2	BEARING RING SC25
2	17157	2	CROSS & BEARING KIT	13	16815	1	SAFETY CHAIN
3	17158	2	SPRING PIN 10x90	14	16818	2	SCREW- IN ITEM 9 & 19
4	17159	1	INBOARD YOKE S4	15	16816	1	DECAL OUT. FOR ITEM 10
5	50638	1	INBOARD PROFILE S4	16	16817	1	DECAL INN. FOR ITEM 6
6	50639	1	PROFILE & SLEEVE	17	17171	1	SUPPORT BEARING
7	17162	1	INBOARD YOKE S5	18	16820	1	ZERK IN ITEM 6
8	50642	1	SHEARBOLT/OVERRUNNING CLUTCH	19	3048	1	BOLT 12mm x 60mm IN ITEM 8
9	17163	2	SHIELD CONE 7-RIB	20	17181	1	NUT 12mm - IN ITEM 8
10	50640	1	OUT. SHIELD TUBE OVAL	21	17173	1	LOCK COLLAR KIT ON ITEM 1
11	50641	1	INN. SHIELD TUBE ROUND				

GRAINCART SHEARBOLT YOKE, PART# 50642



ITEM	PART#	QTY	DESCRIPTION
1	50643	1	YOKE
2	16824	1	ZERK
3	16825	24	BALL
4	50644	1	HOUSING
5	50645	1	HUB
6	50646	2	KEY
7	50647	2	LEAF SPRING
8	50648	1	SUPPORTING RING
9	50649	1	RETAINING RING
10	50486	2	CLAMP BRIDGE
11	50485	2	HEX BOLT 16mm x 110mm
12	3149	2	HEX LOCK NUT 16mm
13	3048	1	HEX BOLT 12mm x 60mm
14	3119	1	HEX LOCK NUT 12mm

GRAINCART 1 3/4-1000 RPM CUT-OUT CLUTCH PTO, PART# 37466




ITEM	PART#	QTY	DESCRIPTION	ITEM	PART#	QTY	DESCRIPTION
1	52065	1	YOKE 1 3/4- 20 SPL OVERRUNNING YOKE	12	16814	2	BEARING RING SC25
2	17157	2	CROSS & BEARING KIT	13	16815	1	SAFETY CHAIN
3	17158	2	SPRING PIN 10x90	14	16818	2	SCREW- IN ITEM 9 & 19
4	17159	1	INBOARD YOKE S4	15	16816	1	DECAL OUT. FOR ITEM 10
5	52066	1	INBOARD PROFILE S4	16	16817	1	DECAL INN. FOR ITEM 6
6	50639	1	PROFILE & SLEEVE	17	17171	1	SUPPORT BEARING
7	17162	1	INBOARD YOKE S5	18	16820	1	ZERK IN ITEM 6
8	52067	1	CUTOUT CLUTCH	19	50454	1	SHIELD CONE 6-RIB
9	17163	1	SHIELD CONE 7-RIB	20	17173	1	LOCK COLLAR KIT ON ITEM 1
10	50640	1	OUT. SHIELD TUBE OVAL	21	52068	1	LOCK COLLAR KIT ON ITEM 8
11	50641	1	INN. SHIELD TUBE ROUND				

Section E

COMPLETE HYDRAULIC OVERRUNNING CLUTCH, P/N 90886


ITEM#	QTY	PART#	DESCRIPTION
1	1		HOUSING
2	4	50472	FRICITION DISK
3	1		HUB, 45mm ROUND
4	1	50481	DRIVE PLATE
5	1	50482	DRIVE PLATE
6	1	50483	SPRING PACK
7	1	50484	SETTING RING
8	1		HYDRAULIC UNIT
9	6		HEX NUT
10	6		SET SCREW
11	6		PLUG



MINIMUM OIL PRESSURE=1175psi
 MAXIMUM OIL PRESSURE=2573psi

Section E


Graincart Gearbox, Part# 80500




Graincart Gearbox, Part# 80500

Item#	Qty	Part#	Description
1	1	50767	HOUSING GEARBOX - 1000 GRAIN CART GEARBOX
2	1	22602	BEARING CUP
3	1	50768	BEARING CONE GRAIN CART GEARBOX
4	1	50769	BEARING CONE GRAIN CART GERABOX
5	2	50770	BEARING CUP GRAIN CART GEARBOX
6	1	50771	SEAL OIL GRAIN CART GEARBOX
7	1	50524	SEAL PRAIRIE #1499SHREDDER GEARBOX 1000 RPM2" ID FOR INPUT SHAFT
8	1	22604	SHIM .007 (COVER) PRAIRIE #1544
9	1	50781	SHIM 2"ID X .007 THK GRAIN CART GEARBOX
10	1	50782	SHIM 2.25" ID GRAIN CART GEARBOX
11	1	50780	GASKET, COVER PLATE GRAIN CART GEARBOX
12	2	50783	SNAP RING GRAIN CART GEARBOX
13	8	1206	BOLT.37 X 1 HEXHEAD GRADE 5 Z.P.
14	8	1204	BOLT.37 X .75 HEXHEAD GRADE 5 Z.P.
15	1	6997	PLUG DRAIN HEX SOC .25 NPT
16	1	8907	PIPE PLUG .50-14 NPTF SQ HD
17	1	50785	VENT 1/2" NPT GRAIN CART GEARBOX
18	1	50417	WASHER 2"ID X .179 OUTPUT SHAFTPUMP VERTICAL LAGOON
19	2	50784	WASHER 2.25"ID X .179 GRAIN CART GEARBOX
20	1	50778	PLATE COVER GRAIN CART GEARBOX
21	1	50779	COVER OPEN GRAIN CART GEARBOX
22	1	50774	GEAR 27T GRAIN CART GEARBOX
23	1	50775	PINION 20T GRAIN CART GEARBOX
24	1	50776	SHAFT THRU GRAIN CART GEARBOX
25	1	50777	SHAFT QUILL GRAIN CART GERABOX
26	1	50772	BEARING CONE GRAIN CART GEARBOX
27	1	13149	BEARING CUP INNER 382A 8 BOLT HVY
28	1	13150	BEARING CONE INNER
29	1	50773	SEAL OIL GRAIN CART GERABOX2.25" ID X 3.876" OD

Section E




ITEM #	QTY	PART #	DESCRIPTION	ITEM #	QTY	PART #	DESCRIPTION
1	1	81025	PRESSURE REDUCING VALVE ASBY	10	1	-	BUTTERFLY ARM RH (SEE HUB & SPINDLE CHART)
2	1	28388	HITCH DOUBLE TANG	11	1	-	BUTTERFLY ARM LH (SEE HUB & SPINDLE CHART)
3	1	90472	HITCH MOUNT 4200 - 7500	12	4	-	HUB (SEE HUB & SPINDLE CHART)
4	1	90646	PIN & CHAIN .63x3 WORKING	13	4	-	TIRE ASSEMBLY (SEE HUB SPINDLE CHART)
5	1	83338	SIMOL CRANK JACK W/BACKET	14	2	40761	CYLINDER, HYD
6	8	90633	MOUNTING BRACKET, LONG SHAFT	15	4	80592	COVER, KING PIN TOP
7	8	90631	WEIGH BAR	16	4	80594	O-RING 3 3/4" ID
8	8	90632	MOUNTING BRACKET, SHORT SHAFT	17	4	80595	O-RING 2 1/2" ID
9	1	82475	AXLE WELDMENT HEAVY 60" FRAME	18	4	28089	BUSHING TENSION



ITEM #	QTY	PART #	DESCRIPTION	ITEM #	QTY	PART #	DESCRIPTION
1	1	81025	PRESSURE REDUCING VALVE ASBY	11	3	82484	SWAY BAR - GRAIN CART TRIDEM
2	1	91774	PIN WELD SWMVEL PINTLE 2.25"	12	6	-	HUB (SEE HUB & SPINDLE CHART)
3	2	91779	HITCH RETAINING PLATE	13	6	-	TIRE ASSEMBLY (SEE HUB SPINDLE CHART)
4	1	90646	PIN & CHAIN .63x3 WORKING	14	6	40761	CYLINDER, HYD
5	1	83338	SIMOL CRANK JACK W/BACKET	15	12	80592	COVER, KING PIN TOP
6	8	90633	MOUNTING BRACKET, LONG SHAFT	16	12	80594	O-RING 3 3/4" ID
7	8	90631	WEIGH BAR	17	12	80595	O-RING 2 1/2" ID
8	8	90632	MOUNTING BRACKET, SHORT SHAFT	18	12	28089	BUSHING TENSION
9	1	90701	AXLE ASBY FIXED	19	6	41571	CYLINDER HYD 3.5 x 16
10	2	90702	AXLE ASBY 5" STEER	20	12	41193	LINKAGE BAR WELDMENT


Grain Cart Hub Spindles

HUB & SPINDLES	10-BOLT 5"SLD 13.18" B.C. W/O BRK	10-BOLT 5" SLD 13.18" B.C. W/2 WHL BRK	10-BOLT 5" TRK 13.18" B.C. W/O BRK	10-BOLT 6" SLD 13.18" B.C. W/4 WHL BRK	10-BOLT 6" SLD 13.18" B.C. W/2 WHL BRK
TANDEM BUTTERFLY ARMS	82471	82343	82471	83181	82341
	82470	82342	82470	83180	82340
TRIDEM AXLE FIXED	90701	90701	90701	NOT AVAIL	NOT AVAIL
TRIDEM AXLE STEERING	90702	92840	90702	NOT AVAIL	NOT AVAIL
LUG TIRES 30.5x32 R1 12PLY	90029	90029	90029		90029
LUG TIRES 800/65R32 R1	82335		82335		
LUG TIRES 900/60-32 R1	91900		91900	91900	
TURF TIRES 18.4x26 R3	28205	28205	28205		28205
TURF TIRES 28Lx26 R3	28386	28386	28386		
TURF TIRES 30.5x32 R3 12PLY	27674	27674	27674		27674
TURF TIRES 30.5R32 R3 12PLY	92640	92640	92640		92640
TURF TIRES 30.5x32 R3 16PLY	91590	91590	91590		91590
TURF TIRES 35.5x32 R3 12PLY				83355	
HUB SPINDLE, NO BRAKE	91854	91854	92072	91855	91855
HUB SPINDLE, LH		82189	92071	82192	82192
HUB SPINDLE, RH		82189	92070	82192	82192
COMPLETE HUB ASSY	91850	91850		91851	91851
HUB W/CUPS & STUDS	50814	50814	50799	50818	50818
INNER CUP	21651	21651	21651	50819	50819
OUTER CUP	21652	21652	21652	50820	50820
STUDS OR BOLTS	50400	50400	50400	50400	50400
WHEEL NUT	91849	91849	91489	91849	91849
WHEEL NUT WASHER					
INNER CONE	21622	21622	21622	50821	50821
OUTER CONE	21621	21621	21621	50822	50822
HUB CAP	17149	17149	21630	50823	50823
HUB CAP GASKET	17147	17147	21629	50824	50824
HUB CAP BOLTS	1181	1181	1183	1181	1181
SEAL	50815	50815	21620	50825	50825
GREASE ZERK	2291	2291		2291	2291
COMPLETE SPINDLE	91856	91856		91875	91875
SPINDLE	50816	50816	21641	50829	50829
CASTLE NUT	50817	50817		50827	50827
COTTER PIN/ROLL PIN	81767	81767		1953	1953
FLAT WASHER	11814	11814		50828	50828
SPINDLE LOCKWASHER			21624		
SPINDLE STARWASHER			21623		
INNER SPINDLE NUT			21626		
OUTER SPINDLE NUT			21625		
BRAKE DRUM OR BRAKE ROTOR	91859	91859		91858	91858
BRAKE CALIPER	91853	91853		91853	91853
STUD BOLTS CENTER TO CENTER	13.2"	13.2"	13.2"	13.2"	13.2"
BRAKE MNTG. PAT.	10-11BC	10-11BC		10-11BC	10-11BC
WHEEL PILOT WHOLE	11.25"	11.25"	11.25"	11.25"	11.25"



ITEM #	QTY	PART #	DESCRIPTION
1	1	90668	BEARING MOUNT MID .375x3x12
2	1	90587	COVER, REAR HORT AUGER
3	1	26872	FLANGE BEARING 2 3/16"
4	1	90661	HANGER BEARING
5	1	90451	AUGER 20" HORIZ REAR
6	1	90886	FRICTION CLUTCH
7	1	90586	COUPLER SHAFT 2"DX4.5 .5KY
8	1	90676	ELBOW 90 DEG 1/8NPT
9	1	90677	PIPE, LONG, NIPPLE BOTH ENDS
10	1	12333	COUPLER PIPE 1/8" NPT
11	1	2292	ZERK .25 - 28 45 DEG
12	1	81157	CLEANOUT DOOR LATCH
13	1	81156	DOOR BOTTOM TROUGH
14	1	80898	BEARING-INSERT 1 5/16" w/o SNAP RING
15	1	80896	BEARING-INSERT 1 5/16" BORE

Section E




ITEM #	QTY	PART #	DESCRIPTION
1	1	92421	LOWER 24" AUGER ASBY 04-05
2	1	92422	UPPER AUGER 24" ASBY 04-05
3	1	91308	LINKAGE ARM LOWER WELD
4	1	91323	HINGE PIN WELDMENT
5	4	81767	ROLL PIN 3/8" x 3" LONG
6	4	81768	WASH 2" ID 3" OD
7	1	91331	PIN 1.94" DIA x 10.13" WELD
8	1	91304	LINKAGE ARM UPPER PIVOT
9	1	91259	HYD CYL 6x22 SOFT LANDING
10	2	91333	PIN 1.94"DIA x 9.13" WELD
11	1	60984	WORK LIGHT 3x5 HALOGEN
12	1	92270	HANDWHEEL KIT

**Vertical Auger
Sub Assembly**


Lower Vertical Auger Sub Assembly

ITEM #	QTY	PART #	DESCRIPTION
1	1	92137	AUGER HSG LOWER 24" 04-05
2	1	91275	AUGER 24" LOWER - WELDMENT
3	1	90575	Mid Bearing Weld
4	1	92423	POWER TRANSFER COUPLER 04-05
5	1	26872	FLANGE BEARING 2 3/16"
6	1	60154	FLANGE BEARING 2.18" 4-BOLT
7	1	80414	CLEANOUT DOOR
8	1	41704	COVER, ACCESS HOLE
9	1	80500	GEAR BOX
10	1	91322	SHIELD LOWER DRIVE REAR
11	1	91321	SHIELD LOWER DRIVE MIDDLE
12	1	17354	PLATE, COVER (CLEAN OUT)
13	1	41729	FRONT COVER VERT AUGER
14	2	80508	SPROCKET, IDLER DOUBLE
15	1	80504	SPROCKET, D100ATL18-2517
16	2	80511	BUSHING TAPERLOCK 2517 x 2"
17	1	80505	SPROCKET D100A18
18	1	80512	BUSHING TAPERLOCK 3020
19	1	80506	SPROCKET D100ATL36-3020
20	1	91320	SHIELD LOWER DRIVE FRONT
21	1	90588	COVER CLEAN OUT 24" AUGER
22	1	90738	SHIELD GEARBOX 24" AUGER
23	1	91331	PIN 1.94" DIA x 10.13" WELD
24	1	81767	ROLL PIN 3/8" x 3" LONG
25	1	91376	SPACER WELD
26	1	91256	AUGER STORAGE BRACKET WELD
27	1	91257	RUBBER BELTING 1x4x25
28	1	81768	WASH 2" ID 3" OD
29	1	92413	SPACER 1/8 X 2 3/16" ID X 2 7/8" OD
30	1	92414	SPACER 3/8 X 2 3/16" ID X 2 7/8" OD
31	1	92415	SPACER 1/4 X 2 3/16" ID X 2 7/8" OD
32	1	83313	PLATE COVER 5" X 16" X 1/2 GA.



Section E

Upper Vertical Auger Sub Assembly



ITEM #	QTY	PART #	DESCRIPTION
1	1	92138	UPPER AUGER HSG 24" 04-05
2	1	60154	FLANGE BEARING 2.18" 4-BOLT
3	1	92427	AUGER UPPER 24" 04-05
4	4	90596	SPRING COMPRESSION .71 ID x 3.5"
5	1	91588	PIN .5x3.5 SPIROL
6	2	90598	WASHER 7ga 2.25"ID x 3.5"OD
7	2	92140	SPOUT EXTENSION EXPORT
8	1	92436	RUBBER SPOUT 04-05
9	1	92437	FLAT RETAINER w/HOLES 04-05

DETAIL B
SCALE 1 : 10


SECTION A-A
SCALE 1 : 30

Parts




Section E

Hyd. Door, Light Bar, Chain Oiler, & Windows




ITEM #	QTY	PART #	DESCRIPTION
1	1	92530	TARP KIT
2	1	92270	HANDWHEEL KIT
3	1	33224	RUBBER BOOT FOR 27701
4	1	27702	PLUG ELECT 7 CONNECTOR FML
5	1	26325	OIL RESERVOIR T GAL
6	1	4061	SIGHT GLASS 2" NPT
7	1	4062	O RING 2.3" ID x .141 THK
8	2	90319	RUBBER SEAL-WEATHERSTRIP
9	2	90318	WINDOW IN GRAIN CART
10	4	82143	DOOR ADJUSTMENT BAR
11	1	8226	CYLINDER 2.5 X 10
12	2	82158	PLATE 3/8" MOUNTING
13	1	82145	HYD CYD MOUNT WELDMENT
14	2	91352	LIGHT BRACKET WELD
15	1	40762	RT LIGHT
16	1	40763	LT LIGHT
17	2	82153	SHIELD WELDMENT HYD DOORS
18	2	90247	VALVE 1/8" FPT x 1/8" FPT

1250 Extension Kit




ITEM NO.	QTY.	PART NO.	DESCRIPTION
1	1	83781	EXTENSION BOARD END REAR 1250
2	2	83789	CORNER ANGLE LH SIDE 1250
3	2	83799	CORNER ANGLE RH SIDE 1250
4	1	83791	EXTENSION BOARD TALL LH REAR
5	1	83792	EXTENSION BOARD TALL LH FRONT
6	1	83783	EXTENSION BOARD END FRONT
7	1	83795	EXT BOARD RH REAR
8	2	83778	SPLICE PLATE SHORT RH 1250
9	2	83777	SPLICE PLATE LH SIDE 1250
10	1	83796	EXT BOARD SHORT RH FRONT
11	1	83785	EXTENSION BOARD TALL LH CENTER
12	1	83787	EXTENSION BOARD RH CENTER
13	2	83774	RUBBER BELTING 1/8"x12"x18
14	2	83773	RUBBER BELTING 1/8"x12"x26 2005
15	3	92817	CHAIN STRAIGHT LINK 5/0




Parts

1500 Extension Kit




ITEM NO.	QTY.	PART NO.	DESCRIPTION
1	1	192791	EXTENSION BOARD END REAR
2	2	92811	CORNER ANGLE LH TALL 1500
3	2	92812	CORNER ANGLE RH SHORT 1500
4	1	192797	EXTENSION BOARD TALL LH REAR
5	1	192799	EXTENSION BOARD TALL LH FRONT
6	1	192795	EXTENSION BOARD END FRONT
7	1	92804	EXT BOARD RH REAR 1500
8	2	92813	SPICE PLATE SHORT RH 1500
9	2	92814	SPICE PLATE LH SIDE 1500
10	1	192807	EXT BOARD SHORT RH FRONT
11	1	192802	EXTENSION BOARD TALL LH CENTER
12	1	192809	EXTENSION BOARD RH CENTER
13	2	83773	RUBBER BELTING 1/8"X12X26 2005
14	2	92816	RUBBER BELTING 1/8"X12X34
15	3	92817	CHAIN STRAIGHT LINK 5/0




Section E

1000 TANDEM GRAIN CART




Section E

1250 TANDEM GRAIN CART WITH WEIGHT BARS



**1500 TRIDEM GRAIN CART
WITH WEIGHT BARS**



IT IS THE POLICY OF BALZER COMPANY TO CONSTANTLY IMPROVE ITS PRODUCTS WHENEVER IT IS PRACTICAL TO DO SO. THEREFORE, BALZER COMPANY RESERVES THE RIGHT TO REDESIGN OR CHANGE ITS EQUIPMENT OR COMPONENT PARTS THEREOF WITHOUT INCURRING THE OBLIGATION TO INSTALL OR FURNISH SUCH CHANGES ON EQUIPMENT PREVIOUSLY DELIVERED.

INSTRUCTIONS FOR ORDERING PARTS

To enable our customer service department to provide you with the correct replacement parts promptly and accurately, follow the ordering instructions as listed below.

Identify your equipment by serial number whenever possible.

Use part numbers and descriptions from the illustration drawings furnished to assist in identifying the needed parts.

Owners, order all parts through your local dealer.

Dealers must indicate company name, shipping point and mailing address for notification if different from shipping point. State whether freight, express, parcel or other handling is desired.

Send all parts to:

BALZER INC.

County Road 27 Box 458

Mountain Lake, MN 56159



INSTRUCTIONS FOR RETURNING PARTS FOR ADJUSTMENT

Dealers should inspect all parts when received. Shortages or damage should be noted by the carrier agent at the time the parts are accepted. Shippers responsibility ceases upon delivery of shipment to customer in good order. Claims for damage, loss, or malfunction are to be reported within thirty (30) days for warranty considerations.

All returned parts must have return authorization, a copy of the original packing list and transportation prepaid.

For replacement parts contact:

Ken Classen Extension 104

Doug Wellman Extension 108

For service contact Dave Bennet at
Extension 134 or at his mobile number:
(612) 839-9968

Phone Number: (800) 795-8551

(800) 727-3133

Main: (507) 427-3133

Fax Number: (507) 427-3640

Website: <http://www.balzerinc.com>



