



UM-MST-2

March 16, 2015
ECR: 101408R

BALZER



MAGNUM SLURRY TANK (TRIDEM) USER MANUAL

Serial Number: _____

Date of Purchase: _____

Purchased From: _____

Dealer's Address: _____

Dealer's Telephone: _____

INDEX

Company Statements	1	Maintenance	25
Accuracy Statement	1	Daily and Before Start of Season	26
To the Purchaser	1	Every 40 Hours	28
Warranty Manufacture	1	End of Season/Prepare for Storage	28
Certificate of General Equipment Warranty	1	Steering System Lubrication	28
Liability for Delays	2	Hub Lubrication	29
Contact Information	2	Hitch Lubrication	29
Warranty Registration	3	PTO Shaft Lubrication	29
Safety	5	Suspension Height Adjustment	30
Mandatory Shut Down Procedure	6	Steering Axle Toe Adjustment	31
Additional Safety Reminders	7	Brake System	32
Personal Safety	7	Adding Brake Fluid	32
Towing Safety	7	Bleeding the Brake System	33
Operation Safety	8	Troubleshooting	37
Hydraulic System Safety	8	Steering Not Working Correctly	38
PTO Operation Safety	9	Backing Up and Steering Not Locked Straight.	38
Safety Signs and Decals	10	Hydraulic Controls Not Working Properly	38
Technical Data	11	Brakes Not Working Properly	38
Specifications	12	PTO Not Working	38
Dimensions	13	Slurry Pump Not Working	39
Operation	15	Rite Rate Flow System	39
Pre-Operation Checks	16	Rite Rate Flow System Programming	40
Hydraulic Hose Color Markings	16	Rite Rate Console Cable Preparation	41
Attaching to Tractor	16	Rite Rate Wiring Installation	42
Initial Start Up	17		
Tank Loading Procedure	17		
PTO Drive System	18		
Hydraulic Drive System	18		
Jack Storage	18		
Independent Cross Axle Steering System	19		
Suspension Hydraulics	20		
Suspension Limits	22		
Braking System	22		
Brake Operations	22		
Brake Fluid Level Check	22		
Rite Rate Flow System	22		
Rite Rate Flow System Field Operation	24		

Accuracy

Balzer Incorporated is dedicated to providing the most reliable and durable agricultural related products available. We have made every attempt to provide the most accurate and readily understandable information on our equipment. Due to our continuing efforts to produce the best products available, updates and improvements to our equipment may precede updates to this and other manuals. Therefore, the contents of this manual are based on the information in effect at the time of publication and are subject to change without notice.

It is the policy of Balzer Incorporated to constantly improve its products whenever it is practical to do so. Therefore, Balzer Incorporated reserves the right to redesign or change its equipment or component parts thereof without incurring the obligation to install or furnish such changes on equipment manufactured prior to date of redesign or change.

To the Purchaser



This is the safety alert symbol. It is used to alert the operator to an instruction concerning the personal safety and risk factor of this equipment. Always observe and heed these very important instructions to promote a safe operation with good preventive maintenance habits.

This Balzer product is designed and manufactured to provide years of dependable service when used for the purpose for which it is intended, and when properly maintained.

NEVER OPERATE THIS EQUIPMENT AT SPEEDS OVER 20 MPH.

NEVER OPERATE THIS EQUIPMENT UNTIL USER FULLY UNDERSTANDS THE COMPLETE CONTENTS OF THIS MANUAL. FOR OWNERS WHO DO NOT OPERATE THIS EQUIPMENT, IT IS THE OWNER'S RESPONSIBILITY TO ENSURE ALL USERS ARE PROPERLY INSTRUCTED AND FULLY AWARE OF THIS MANUAL'S CONTENTS.

This is important in the safe handling of this equipment and promoting an efficient operation. If there are any questions about areas in this manual, it is important to contact your dealer for clarification.

This machine is warranted as stated below. Registration of this equipment is to be completed online as soon as possible. This will provide a ready reference to help you in securing warranty and in answering questions that you may have at some later date.

Operating instructions and parts manuals are shipped with this machine. If parts of these manuals are missing or become unreadable, contact your dealer for a replacement manual.

The serial number and identification tag is located to the front of the frame. Please refer to these numbers when parts or warranty communication is necessary.

Warranty Manufacture

The Dealer or Distributor understands and agrees the Manufacturer extends only the following Warranty to customers. In the event a Dealer or Distributor extends any additional warranty (such as by enlarging the scope or period of warranty or undertaking a warranty of merchantability or fitness for any particular purpose) or any other obligation whatsoever, the Dealer or Distributor shall: (1) be solely responsible therefore; (2) have no recourse against the Manufacturer thereof; and (3) defend, indemnify, and hold the Manufacturer harmless against any claim or cause of action whatsoever arising out of, or occasioned by, the Dealer's or Distributor's extension of said additional warranty or obligation.

Certificate of General Equipment Warranty

Balzer Inc. warrants new Products sold by it to be free from defects in material and/or workmanship for a period of one (1) year after the date of delivery to the first user and is subject to the following conditions:

1. Balzer Inc.'s obligation and liability under this Warranty is expressly limited to repairing or replacing at Balzer Inc.'s option any parts which, upon inspection by Balzer Inc., to have been defective in material or workmanship. Such parts shall be provided at no cost to the user and shall be delivered to the business establishment of the authorized Balzer Inc. dealer or distributor of the Product during that dealer's or distributor's regular working hours.
2. This Warranty shall NOT apply to component parts or accessories of Products not manufactured by Balzer Inc. and which carry the warranty of the manufacturer thereof, or to normal maintenance (such as tune-up) or normal maintenance parts (such as oil filters).
3. Replacement or repair parts installed in this Product covered by this Warranty are warranted only for the remainder of this Warranty if such parts replaced were original components of said Product.

Certificate of General Equipment Warranty (Continued)

BALZER INC. MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, AND MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

Balzer Inc.'s obligation under this Warranty shall not include any transportation charges, cost of installation, duty taxes, or any other charges whatsoever, or any liability for direct, indirect, incidental, or consequential damage or delay. If requested by Balzer Inc., products or parts for which a warranty claim is made are to be returned transportation prepaid to Balzer Inc. This Warranty shall become void under, but not limited to, any of the following conditions: any improper use, including operation after discovery of defective or worn parts, operation beyond rated capacity, or operation for a use other than this Product's intended design; substitution of parts not approved by Balzer Inc.; or modifications or repairs by others that are done in a manner as determined by the judgment of Balzer Inc. to have adversely affected the material or workmanship of this Product.

NO EMPLOYEE OR REPRESENTATIVE IS AUTHORIZED TO CHANGE THIS WARRANTY IN ANY WAY OR GRANT ANY OTHER WARRANTY UNLESS SUCH CHANGE IS MADE IN WRITING AND SIGNED BY AN OFFICER OF BALZER INC. AT ITS HOME OFFICE.

Liability for Delays

No liability shall attach to Manufacturer direct or indirect for incidental or consequential damages or expenses due to loss, damage, detention of, or delay in delivery of Products resulting from acts or delays beyond its control.

Contact Information

Telephone Numbers

Toll-Free: (800) 795-8551
(800) 727-3133
Outside North America: (507) 427-3133
Fax: (507) 427-3640

Mailing/Shipping

Balzer Inc.
County Road 27 East
PO Box 458
Mountain Lake, MN 56159


Website

www.balzerinc.com


Warranty Registration

As of June 1, 2014, all warranty registration must be completed online to be valid. Registering online is fast and easy. If you are viewing this manual on a device connected to the Internet, click here: **REGISTER NOW!**

Go to the Balzer website at www.balzerinc.com and click on "Parts and Service".



Then, on the right side of the website, click on the "Register Now" button under "Warranty Registration".



Complete the online form and click "Submit".

Warranty Registration

Thank you for your recent purchase. Complete the following form to register your product warranty. *Warranty is not valid unless this form is completed.

Product:

Model Number: Serial Number:

Purchase Date:

Customer Name:

Customer Phone: Customer Email:

Customer Address:

Customer City: Customer State: Customer Zip:

Dealer Name:

Dealer Address:

Dealer City: Dealer State: Dealer Zip:

Submit

Balzer Inc. is committed to our customers and their privacy. Balzer Inc. will only use the information you give us to provide prompt warranty claims and services to you. Balzer Inc. uses appropriate safeguards which reasonably and appropriately protect the information that Balzer Inc. creates, receives, maintains, or transmits on behalf of our customers. Any personally identifiable information obtained will not be sold, rented, shared, or made available to third parties.

The logo for BALZER is rendered in a bold, italicized, sans-serif font. The letters are black with a white outline and a slight drop shadow, giving it a three-dimensional appearance. It is positioned at the top of the page, partially overlapping a green diagonal band that runs from the top left towards the center right.

BALZER

Safety

The following Safety Alert Symbols mean **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!** They stress an attitude of “**HEADS UP FOR SAFETY**” and can be found throughout this manual and on the equipment itself.

BEFORE YOU ATTEMPT TO OPERATE, MAINTAIN, OR SERVICE THIS EQUIPMENT, READ AND STUDY THE FOLLOWING SAFETY INFORMATION. IN ADDITION, MAKE SURE THAT EVERY INDIVIDUAL WHO OPERATES, WORKS WITH, OR OTHERWISE USES THIS EQUIPMENT IS FAMILIAR WITH THESE SAFETY PRECAUTIONS.

Our company **ALWAYS** takes operator safety into consideration when designing its machinery, guards, and exposed moving parts for operator protection. However, some areas can **NOT** be guarded or shielded in order to assure proper operation. In addition to this manual, decals on the machine warn of further danger and should be read and observed closely.

READ and **FOLLOW** the instructions on all decals.

REMEMBER it is the owner’s responsibility for communicating all information on the safe use and proper maintenance of this machine! This includes providing understandable interpretation of these instructions for operators who are not fluent in reading or understanding English.

	DANGER	DANGER indicates an imminently hazardous situation which if not avoided will result in serious injury or death or irreparable damage to the machine.
--	---------------	---

	WARNING	WARNING indicates a potentially hazardous situation which if not avoided may result in serious injury or death or moderate to severe damage to the machine.
--	----------------	--

	CAUTION	CAUTION indicates a potentially hazardous situation which if not avoided may result in minor to moderate injury or minor to moderate damage to the machine.
--	----------------	--

Mandatory Safety Shutdown Procedure

BEFORE cleaning, adjusting, lubricating, or servicing this equipment:

1. Remove the ignition key from the power unit engine.
2. Make sure ALL movement throughout this equipment has ceased! **ONLY** when you have taken these precautions can you be sure it is safe to proceed. Failure to follow the above procedure may lead to serious injury or death.
3. Properly attach the jack to this equipment and raise up to transfer weight to the jack.
4. Keep the hitch pin attached to help prevent this equipment from moving.
5. Disconnect the PTO shaft from the power unit.

Additional Safety Reminders

USER/OPERATOR SAFETY PRACTICES are included in this manual and are intended to promote **SAFE OPERATION** of this equipment.

These guidelines do not preclude the use of good judgment, care, and common sense as may be indicated by the particular job site work conditions.

It is essential that all operators be physically and mentally free of any mind altering drugs and chemicals and thoroughly trained in the safe operation of this equipment. Such training should be presented completely to all new operators and **NOT** condensed for those claiming previous experience.

FOR ILLUSTRATION PURPOSES ONLY some photographs and images in this manual may show doors, guards, and shields open or removed. **BE SURE** all doors, guards, and shields are in their proper operating positions **BEFORE** operating this equipment. **NEVER** operate this equipment with any guards or shields damaged or not in place. **REPLACE** any damaged or missing guards and shields.

KEEP HANDS AND FEET AWAY FROM ALL MOVING PARTS!

The operator **MUST** know the capabilities and work applications for this equipment and operate it at speeds slow enough to ensure complete control at all times. When working on uneven ground or near the edge of roadbeds there is no substitute for good judgment and only operators with sufficient experience should attempt such work.

NEVER assume everyone is as safety conscious as you are.

Personal Safety

NEVER allow minors and/or any unqualified personnel to operate or be near this equipment unless properly supervised.

NEVER allow anyone to ride on this equipment at any time.

NEVER leave this equipment running unattended.

NEVER wear loose or torn clothing while working around moving parts.

NEVER step on the PTO drive shaft at any time.

ALWAYS wear appropriate personal safety equipment and gear as called for by the job or working conditions.

ALWAYS be aware of pinch point areas on this equipment.

ALWAYS keep hands, feet, hair, and clothing away from moving parts.

ALWAYS stop and disengage the PTO and shut off the tractor before doing any adjusting or servicing to this equipment.

Towing Safety

THE MAXIMUM SPEED FOR TOWING THIS EQUIPMENT IS 20 MPH.

Observe the recommended maximum road speed limit, local speed limit, or maximum recommended towing speed whichever is the lesser speed.

ALWAYS MOVE THIS EQUIPMENT WITH A FARM TRACTOR ONLY.

Always engage power steering (on equipment with steering capabilities) before turning with a load.

DO NOT DISENGAGE power steering (on equipment with steering capabilities) before the turning process is completed.

Tractor must be heavy and powerful enough and have adequate braking power for the towed load.

STOPPING DISTANCE increases with speed and weight of towed loads and on slopes. Towed loads, with or without brakes, which are too heavy for the tractor or are towed too fast can cause loss of control. Consider the total weight of all equipment and the load.

Use additional caution when towing loads under adverse surface conditions (ice, mud, loose gravel, etc.), turning, or slopes.

DO NOT ATTACH safety chain to any point higher than the drawbar.

Operation Safety

Before each tow check the electrical connection, tail lights, brake lights, and turn signals. Damaged lights or improper electrical connection between the tractor and this equipment will result in inoperable lights and/or inoperable electric brakes.

Do not operate on public roads after dark without warning lights.

Be sure the rear of this equipment has a visible and clean “Slow Moving Vehicle” emblem properly displayed. If towing at speeds less than 20 MPH on any public roadway at night, proper warning and running lights are necessary as required by state law!

DO NOT pull this equipment without having safety chains (not supplied) securing this equipment to the tractor.

Refer to local transportation laws for regulation on safety chain use. **MAXIMUM TOWING SPEED IS 20 MPH.**

The tractor must be of sufficient size to maintain vehicle stability when this equipment is fully loaded.

ALWAYS use a hitch pin which has a safety clip pin!

If this equipment includes a braking system, check oil level and braking capacity with a full load before operating or moving this equipment.

Check the wheel lug bolts and lug nuts daily and tighten as needed.

Replace any parts showing signs of excessive wear, cracking, or likelihood of failure with original equipment service parts.

Be familiar with all valves, doors, gates, and hydraulic controls.

BEFORE USE make sure this equipment does **NOT** have any foreign objects or materials which can cause equipment damage or personal injury.

NEVER ENTER THIS EQUIPMENT UNLESS ABSOLUTELY NECESSARY! If entry is necessary, take proper safety precautions to include but not limited to:

- Additional person on site and on the outside near the point of entry
- Safety harness and ropes where appropriate or required by law
- Proper life support system where appropriate or required by law
- Mechanical and electrical power disconnected
- Contacting your Balzer dealer for more information before entering

Check that the PTO slides freely, is not damaged, and is properly secured to the tractor and this equipment. Make sure there is approximately 1/3 overlap of engagement. (Refer to Figure 7: Drawbar Adjustment on Page 16.)

Be alert and avoid loose, soft, or icy surface conditions which could cause tipping or loss of control.

When possible, travel straight up or down a slope. Avoid traveling along side of hills, ditches, or other sloped surfaces.

Slow down prior to going down any steep grade.

Always check the job site for hazardous terrain, obstructions, or bystanders.

Never take tractor out of gear when going up or down a hill.

Do not exceed the maximum weight carrying capacity of the equipment or the tractor manufacturer's maximum towing capacity, whichever is the lesser weight. If you have any questions, contact your Balzer dealer.

Never use a tractor that is not recommended for this equipment's application.

When agitating a pit, always make sure there is adequate ventilation in any confined area.

Do not stand in front, behind, or along side this equipment when it is in operation or in motion.

When parking this equipment, securely block the wheels before unhitching from the tractor.

Hydraulic System Safety

DO NOT smoke when working on hydraulic systems.

NEVER use your hand to search for hydraulic fluid leaks. Escaping fluid under pressure can be invisible and can penetrate the skin causing serious injury and other health hazards. Escaping fluid can also be extremely hot causing severe burns.

Use a scrap piece of cardboard to check for leaks.

Hydraulic System Safety (Continued)

IF ANY FLUID IS INJECTED INTO YOUR SKIN, SEEK MEDICAL ATTENTION IMMEDIATELY! Notify medical staff that there is an injection injury with hydraulic fluid. Injected fluid must be surgically removed by a doctor familiar with this type of injury or gangrene may result.

DO NOT attempt to loosen or disconnect any lines, hoses, or fittings without first relieving hydraulic circuit pressure. Be careful not to touch any hydraulic components recently in operation because they can be extremely hot.

ALWAYS replace hydraulic components with manufacturer recommended replacement parts. Improperly rated components may result in system failure and/or injuries.

Contact your local Balzer dealer to order replacement parts.

PTO Operation Safety

Do not wear loose fitting clothing or have long, free-hanging hair when operating the PTO (Power Take Off) or near ANY rotating equipment.

Never exceed the recommended operating speed (PTO and drive) for the particular equipment in use.

When operating stationary PTO driven equipment, always apply the tractor's parking brake lock and block the rear wheels front and back.

To avoid injury, do not clean, adjust, unclog, or service PTO driven equipment when the tractor engine is running.


When finished with the operation of PTO driven equipment, shift the PTO control to neutral, shut off the engine, remove the key, and wait until the PTO stops before exiting the tractor.



WARNING

PTO mounted drive shafts must only be used for their intended purpose.

Figure 1



DANGER

DO NOT operate PTO without all guards in place and in safe operating condition.

PTO Operation Safety (Continued)

Implement input drivelines, clutches, and freewheels are designed for specific machine types and power requirements. They must not be replaced by any shaft other than that recommended by the implement manufacturer. Note the Operating Instructions from both the tractor manufacturer and the implement manufacturer. Ensure the implement driveline is securely connected at both ends.

Only use a completely guarded drive system (Figure 1). PTO drive systems with complete guarding include: the tractor master shield, the implement driveline guard (end cones, telescoping section sleeves, guard chain), and the implement safety shield. These safety devices must be installed at all times.

If any component of the guarding system has been removed for any reason, it must be repaired or replaced prior to operation of the machine.

Safety Signs and Decals

Safety signs or decals provide very important information and instructions designed to alert you to dangers and hazards which can be present during operation of this equipment. These safety signs and decals **MUST** be read, understood, and followed to be effective.

Replacement of Safety Signs and Decals

Safety signs and decals must be kept clean and readable. If they become unreadable for any reason, they must be replaced with an identical replacement sign or decal. Safety signs and decals must also be replaced if damaged when repairing this equipment or if not included with the replacement part.

Application of Safety Decals

Surface preparation is very important for the safety decals to properly adhere. Grease, oil, and dirt must be removed and the surface must be smooth and dry. After wiping the surface clean, use an ammonia-free window cleaner to provide the best surface for decal adherence.

Most decals have a split backing which is meant to be removed from the split outward. To apply decals, follow these steps:


1. Position the decal in the proper location and hold firmly over the largest portion of the backing.
2. Use one hand to hold the decal in position. With the other hand, carefully roll the loose end over and peel the backing outward. When the backing is removed as shown in Figure 3 and with even and gradual pulling, the decal will roll onto the surface smooth and wrinkle free,
3. With the smallest portion of the decal attached, the repeat Step 2 for the other half of the decal.

When the decal has been attached in place, use a cloth or soft paper towel to burnish the decal onto the cleaned surface. Work gently from the middle outwards to avoid creating any wrinkles and to remove any air bubbles.

Figure 2



Figure 3




The logo for BALZER, featuring the word in a bold, italicized, sans-serif font with a white outline and a grey drop shadow. The logo is positioned on a green diagonal band that runs from the top left towards the bottom right.

BALZER

Technical Data

Figure 4



Dimensions

See "Dimensions" on Page 13

Tire Pressure

28L X 26 R3	26 PSI (180 kPa)
28LR26 R3	54 PSI (372 kPa)
30.5 X 32 R1	33 PSI (228 kPa)
30.5 X 32 R3	33 PSI (228 kPa)
30.5LR32 R1	52 PSI (359 kPa)
30.5LR32 R3	52 PSI (359 kPa)
850/50 30.5	37 PSI (256 kPa)
900/60 32 R1	35 PSI (241 kPa)

Lug Nuts Torque to 450 FT/LBS

Brake Type Disc

Hydraulic Operating Pressure Up to 3000 PSI
(20.68 MPa)

Electrical System 12 VDC

Electrical Connection 7-Way Receptacle

Maximum Tow Speed 20 MPH
(32 KPH)

TRACTOR REQUIREMENTS

PTO Horsepower
Maximum 248 hp

PTO Speed 1000 RPM

Drawbar Max. Vertical Load 4,100 lbs (CAT-3)
(1,860 kgs)

Drawbar Clevis Pin Diameter 2"
(5 cm)

PTO to Drawbar Distance 16" to 20"
(40 cm to 50 cm)

Drawbar to Ground Height Distance 15" to 22"
(38 cm to 56 cm)


Tractor Hydraulic Flow
PTO 10 GPM
(37.8 LPM)

Hydraulic Motor 30 GPM
(113.6 LPM)


Tractor Hydraulic Pressure Up to 3,000 PSI
(20.68 MPa)

Dimensions

Figure 5



Magnum Slurry Tank			
Specification	7500	8500	9500
Overall Length	465" (1181 cm)	465" (1181 cm)	465" (1181 cm)
Overall Width	152 3/8" (387.0 cm)	152 3/8" (387.0 cm)	152 3/8" (387.0 cm)
Overall Height	145" (368.3 cm)	150" (381.0 cm)	155" (393.7 cm)
Tank Length	342" (868.7 cm)	342" (868.7 cm)	342" (868.7 cm)
Tank Diameter	79" (200.7 cm)	84" (213.4 cm)	89" (226.1 cm)
Wheel Base	172" (436.8 cm)	172" (436.8 cm)	172" (436.8 cm)
Clearance	19" (48.25 cm)	19" (48.25 cm)	19" (48.25 cm)
Capacity	7500 Gallons (28,390 Liters)	8500 Gallons (32,175 Liters)	9500 Gallons (35,960 Liters)
Empty Weight	~23,000 lbs (~10,430 kgs)	~24,000 lbs (~10,885 kgs)	~24,500 lbs (11,115 kgs)



The logo for BALZER, featuring the word in a bold, italicized, sans-serif font with a white outline and a grey drop shadow. The logo is positioned on a green diagonal band that runs from the top left towards the bottom right.

BALZER


Operation

Pre-Operation Checks

Make sure all safety shields are in place and properly secured.

Make sure all moving components are free of solid, hard, or frozen material or other obstructions.

Make sure the tractor drawbar matches the standards shown in the Drawbar Adjustment diagram (Figure 7).



Suggested drawbar adjustments for PTO shaft size and speed.



WARNING

Improper PTO Length may damage the unit

Hydraulic Hose Color Markings

Each hydraulic hose will have either one (1) color code stripe indicating it as a Return line or two (2) color code stripes indicating it is a Pressure line. The exception is for the Hydraulic Motor Zero Return line which has two stripes but only one of each color. The following color codes denote the operational purpose of the hydraulic hose lines.

RED - Brakes

GREEN - 3-Way Valve or T-Valve

BLUE - Hydraulic Motor

YELLOW - Steering System

ORANGE - Down Pressure

BLUE/GREEN - Hydraulic Motor Zero Return Line



DANGER

If the unit is equipped with a Zero Return Hydraulic Line it must be connected to a Zero Return Hydraulic connection on the tractor otherwise **DAMAGE TO THE HYDRAULIC MOTOR WILL OCCUR!**

Attaching to Tractor

Attach the tractor's drawbar to the hitch using a properly sized hitch pin. The hitch pin should have a safety retainer to keep it from dislodging itself from the hitch.

Attach the safety chain to the drawbar of the tractor. Attaching the safety chain to a point higher than the drawbar can lead to a potential rollover causing serious injury or death (Figure 8).



DANGER

Attaching the safety chain to any point higher than the drawbar can cause tractor to rollover should this machine become unhitched from the tractor. Tractor rollover can cause serious injury or death!

OPERATION

BALZER

Attaching to the Tractor (Continued)

Crank the trailer jack down to slowly place pressure on the drawbar. After the weight has been transferred to the tractor's drawbar and is no longer being supported by the jack, remove the jack and secure it in its storage location.


Check the tractor's Power Take Off (PTO) for any damage, that it slides freely, and is the proper size and connection for the PTO shaft on the tank.

Attach the PTO shaft to the tractor securely as required by its locking mechanism. The PTO should have approximately 1/3 overlap.

Attach the hydraulic lines making sure the connectors are clean and in good repair. Connect according to the hydraulic hose color and striping pattern listed in the Hydraulic Hose Color Markings section on the previous page.

Connect the 7-Way electrical connector.

Figure 8



Initial Start Up

Never operate this machine if shields are missing, damaged, or improperly installed or if persons are in or on this machine or near any moving parts of this machine. Keep everyone away while operating this machine.

Do not leave the tractor seat.

Operate **ALL** hydraulic controls to become familiar with the function of each tractor lever and to visually see the machine is responding correctly. **NOTE: MAKE MENTAL AND/OR WRITTEN NOTES CONCERNING WHICH WAY TO MOVE THE LEVERS FOR THE DESIRED RESULTS.**

ENGAGE THE PTO SLOWLY with the tractor throttle at slow idle. Use maximum modulation on tractor PTO control.

Watch and listen to confirm the machine is operating properly. Run at fast idle for five (5) minutes, disengage the PTO, shut off the tractor engine, and remove the key from the ignition. Make all necessary adjustments before any further operation of this machine is attempted.



CAUTION

To prevent premature driveline failure, tractor turning should be limited to approximately 10° when driveline is rotating.

Tank Loading Procedure

Position the tank under the load stand or attach filling hose to the Self-Load Function.

Load the tank until full. The flag on top of the tank is attached to a float which will begin to rise when the tank is full. Over filling the tank may result in spillage of manure.

Lower the plow into the ground. If a Down Pressure Block is available, increase or decrease pressure to control the plow's force in the ground.

Engage the hydraulic motor or PTO, whichever the machine is equipped with, to drive the slurry pump.

Begin injecting manure into the ground.

To stop injecting manure into the ground, disengage the hydraulic motor or PTO driving the slurry pump.

Raise the plow.



DANGER

DO NOT TURN the machine if the plow is in the ground. DAMAGE TO THE PLOW WILL OCCUR.

PTO Drive System


If this machine is equipped with a PTO shaft, it will have one of the following shafts (check which shaft is used):

- PTO Shaft, 1 3/8"-21 to 1 1/2" Round with 3/8" Keyway (Standard)
- PTO Shaft, 1 3/4"-20 to 1 1/2" Round with 3/8" Keyway
- PTO Shaft, CV 1 3/8"-21 to 1 1/2" Round with 3/8" Keyway
- PTO Shaft, CV 1 3/4"-20 to 1 1/2" Round with 3/8" Keyway

The PTO shaft will have the 1 1/2" Round with 3/8" Keyway attached to the implement side of the machine. This implement side has a shear bolt to protect the gear box and drive line of the tractor's PTO from overload (Figure 9). The PTO must be engaged slowly, use maximum modulation on the tractor. **DO NOT SLAM ENGAGE THE PTO.**

The PTO shaft should not be extended any more than half the length of the telescoping member overlap.

Figure 9



WARNING

DO NOT slam engage the PTO. Damage to the machine or the tractor may occur at any time during operation following a slam engagement of the PTO.



DANGER

DO NOT OPERATE this machine without all PTO shields and guards in place and properly secured.

Hydraulic Drive System

If this machine is equipped with a hydraulic motor, it will have one of the following (check which motor is used):


- 3.94 CU IN Hydraulic Motor (Standard)
- 6.35 CU IN Hydraulic Motor

When engaging the hydraulic motor, do so slowly to avoid damage to the motor.

Jack Storage


After the machine has been securely attached to the drawbar of the tractor and the jack is no longer supporting the weight of the tongue, finish raising the leg of the jack. Remove the two locking pins (Figure 10), move the jack to the storage location on the tongue, and re-insert the locking pins to secure the jack (Figure 11).

Figure 10



Remove pins and pull the jack off of the support tab.

Figure 11



Slide jack onto storage tab and re-insert pins.



WARNING

DO NOT move or operate this machine with the jack in the support position. Failure to move the jack to the storage position may result in damage to the jack and/or this machine.



WARNING

DO NOT use the jack in the support position unless the tank is empty.

Independent Cross Axle Steering System

The middle axle on this machine is a straight (non-steering) axle and the front and rear axles are the steering axles. The steering on each steering axle is operated by two main components:

- a tie rod
- a hydraulic cylinder

The tie rod has two grease points which must be sufficiently greased at the start of every day's use. Check the kingpins for a grease point (Figure 12). The grease point for the kingpins may be connected to a grease line placing the grease points on the right side rear of the frame. If there is no grease point, the kingpin has a poly bushing which does not need greasing. These grease points must also be greased well after washing and at the end of the season when preparing the machine for storage.

The steering hydraulic cylinders are only used to bring the steering wheels inline with the straight axle for backing up.

Placing the tractor's hydraulic lever into the "Float Position" allows the machine to steer. As the steering wheel of the tractor is turned, the wheels to trail the tractor's direction due to ground pressure allowing maneuverability (Figure 13).

Moving the tractor's hydraulic lever to the "Pressure Position" will position the rod of the cylinder so that the steering wheels line up with those of the straight axle allowing the machine to be backed up with ease. Figure 14 shows the hydraulic connection schematic for the steering hydraulic cylinders.

Figure 12




Figure 13





Figure 14



Suspension Hydraulics

Each axle has two (2) hydraulic cylinders (Figure 15) to transfer the load from the frame to the axle. The axles are attached to the frame by four (4) parallel links, two (2) on each side of each axle, which stabilize the axles and do not support any weight. The hydraulic cylinders on the left side are connected together as are the hydraulic cylinders on the right side (Figure 16). This allows the left side suspension to carry 50% of the weight and the right side suspension to carry the remaining 50% of the weight.

On each side, the base end of the cylinders are hydraulically connected to each other. The base end of the left side suspension cylinders **DO NOT** connect to the base end of the right side suspension cylinders. Once each circuit is charged, the circuit is closed. With the left side cylinders connected to each other and the right side cylinders connected to each other (Figure 17), the hydraulic fluid can flow from one cylinder base to the other on the same side. This allows for the load to equalize and permit the axles to move up or down to negotiate ground variations and field approaches. The fast hydraulic fluid flow between cylinders assures each tire carries the same load as the next without spikes.

The rod ends of all suspension cylinders are connected to a low pressure source to keep them full for seal lubrication. Once filled, the valve is closed (Figure 18).

Figure 15




Figure 16




Figure 18





Figure 19



Suspension Limits

Care must be taken to travel where the suspension system will not be pushed beyond its limits. Each tire can move up or down 7" (17.8 cm) from the center position. Do not exceed these limits or damage to the unit will occur. Promote safe operation and do not go through any deep ditches, over sharp knolls, or grades greater than 9° (15% or 12-2 pitch).



DANGER

DO NOT move this machine through deep ditches, over sharp knolls, or grades greater than 9° (15% or 12-2 pitch).

Braking System

The hydraulic system on some tractors keep a small amount of pressure in the hydraulic lines even when the control lever is set to the "Float" position. The master cylinder on this machine has a pressure releasing spring which is used to counteract this hydraulic pressure coming from the tractor.

The master cylinder of the braking system is designed to create a vacuum in the hydraulic lines leading to the brake calipers. When the brakes are fully released, the vacuum created pulls on the pistons of the calipers causing them to fully retract which disengages the brakes on the machine. However, for this to happen, the master cylinder must never be full of hydraulic fluid when braking.

Brake Operation

Tractors with a "Closed Center" or "Open Center" hydraulic circuit:

1. To apply the brakes, the lever must be pulled fully backward.
2. To release the brakes, the lever must be pushed fully forward to the "Float" position.

Brake Fluid Level Check


1. Apply brakes.
2. Measure the compression of the pressure release spring.
3. If the pressure release spring is compressed to 8" (20.3 cm) or less, hydraulic fluid must be added to the braking system (See "Brake System" on Page 32).

Rite Rate Flow System

The Rite Rate Flow System consists of four components (Figure 19):

- Raven SCS660 NVM Controller and associated cables
- Raven 660 PWM Boost Box
- Krohne Optiflux 4100C Electromagnetic Flow Sensor with Signal Converter
- SkyTrak GPS Velocity Sensor

Figure 19




Rite Rate Flow System (Continued)

Raven SCS660 NVM Controller

The Raven SCS660 NVM Controller (Figure 20) monitors and adjusts the flow rate going to the injector. It has two programmable presets and a manual override allowing for a custom application when necessary.

Figure 20



DANGER

Disconnect power to the Raven SCS660 NVM Controller before jump starting, welding, or charging the battery.

Rite Rate Flow System Field Operation

Pre-Operation Checks

1. Check the hydraulic connections.
2. Before starting the tractor, check all electrical connections at the Raven SCS660 NVM Controller and at the hitch.
3. Start the tractor and turn the Raven SCS660 power **ON** and leave the **MASTER** switch in the **OFF** position. The display on the Raven should light up.
4. Check to see if the Krohne Optiflux Flow Meter is receiving power.
5. Confirm the Raven has the correct programming (See “Rite Rate Flow System Programming” on Page 40).
6. Check to see that the **SPEED CAL** has been set to 598.
7. Check the **BOOM CAL** to see if it is correctly programmed with the proper width (in inches) of your plow/injector toolbar).
8. Check the application rates programmed into **RATE 1 CAL** and **RATE 2 CAL**. If you desire, you can zero out any totals showing for **TOTAL VOLUME**, **TOTAL AREA**, etc.
9. With the tank empty, engage the hydraulics to lower the injector and start the slurry pump. The injector down pressure will be applied but the discharge valve will not open and the pump will not turn with the **MASTER** switch in the **OFF** position. Check the pressure gage at the block to ensure proper down pressure for the injector.
10. Disengage the hydraulic down pressure and lift the injector up.
11. Fill the slurry tank.
12. On the way to the field, check the speed calibration by pressing the  button. The speed displayed should be reasonably accurate when compared to the tractor's speed.

Field Application

1. Upon arrival at the field, make sure the Raven SCS660 has the **POWER** turned **ON**. Set the Flow Control switch to **RATE 1** or **RATE 2** for your desired application rate. Leave the **MASTER** switch **OFF**.
2. Engage the hydraulics to lower the injector and apply down pressure.
3. Turn the **MASTER** switch **ON** and accelerate up to the desired speed. The Rite Rate system will start application as soon as it detects forward movement by the tractor. Quickly you should notice a value displayed next to Rate on the display. Generally the system will initially overshoot the target rate on startup and then slowly back down to the desired preset rate. While the system is settling to the desired rate, the Raven SCS660 may buzz until the correct application rate is reached (about 15-20 seconds). Rate fluctuations of ± 200 gallons per acre are not uncommon with this system. A consistent ground speed during application will help reduce rate fluctuations.
4. During application, the operator may switch the **FLOW CONTROL** back and forth between **RATE 1** and **RATE 2** or switch to **MAN** to manually increase or decrease flow rate. To increase the flow rate, press and hold the switch in the **INC** position until the desired flow rate is reached. To decrease the flow rate, press and hold the switch in the **DEC** position until the desired flow rate is reached. The **FLOW CONTROL** can be switched back to **RATE 1** or **RATE 2** at any time and the system will adjust to that flow rate.
5. Near tile inlets and other areas where tillage is desired but application is not, turn the **MASTER** switch to **OFF**. This will shut off the pump and close the discharge valve. The hydraulics may remain engaged and the injector in the ground.
6. When approaching a turn around location or after the tank has emptied, turn the Master switch to Off and wait 3-4 seconds before raising the injector. This allows the discharge valve time to close and the slurry lines to be cleaned out. Raising the injector before discharge valve becomes fully closed may result in the discharge valve remaining partially open. Do not turn with the injector still in the ground, damage will occur!
7. After completing a turn or refilling the slurry tank and returning to where you left off, repeat Field Application steps 1 through 3.
8. The Rite Rate system will store the programmed data for an extended period of time when disconnected from the power source so the Raven should not need to be reprogrammed.

The logo for BALZER is rendered in a bold, italicized, sans-serif font. The letters are black with a white outline and a grey drop shadow, giving it a three-dimensional appearance. It is positioned at the top of the page, partially overlapping a green diagonal band that runs from the top left towards the center right.

BALZER

Maintenance



CAUTION

Before performing any maintenance on this machine, turn off the tractor, remove the ignition key, and relieve hydraulic pressure from the hydraulic systems unless otherwise noted.

Daily and Before Start of Season


Before Starting Tractor

1. Check tires for damage and proper air pressure. Repair or replace as needed. Tire air pressure should be as listed in Figure 21 below (for future reference check the box next to the tires that came with your machine):
2. Torque all lug nuts to 450 ft/lbs (before first use after purchase, daily for the first five [5] days, before first use of season,

Figure 21



R1 - Lug



R3 - Diamond

Tire Description	Tire Pressure
<input type="checkbox"/> 28L X 26 R3 - 10 Bolt, 13 3/16" Bolt Circle	26 (180 kPa)
<input type="checkbox"/> 28LR26 R3 - 10 Bolt, 13 3/16" Bolt Circle	54 (372 kPa)
<input type="checkbox"/> 30.5x32 R1 - 10 Bolt, 13 3/16" Bolt Circle	33 (228 kPa)
<input type="checkbox"/> 30.5x32 R3 - 10 Bolt, 13 3/16" Bolt Circle	33 (228 kPa)
<input type="checkbox"/> 30.5LR32 R1 - 10 Bolt, 13 3/16" Bolt Circle	52 (359 kPa)
<input type="checkbox"/> 30.5LR32 R3 - 10 Bolt, 13 3/16" Bolt Circle	52 (359 kPa)
<input type="checkbox"/> 850/50 30.5 - 10 Bolt, 13 3/16" Bolt Circle, 10 Ply	37 (256 kPa)
<input type="checkbox"/> 900/60 32 R1 - 10 Bolt, 13 1/4" Bolt Circle	35 (241 kPa)

and after replacing tires).

3. Inspect suspension system for damage. Repair or replace as needed.
4. Inspect all hoses, connections, and reservoirs for leaks. Repair or replace as needed.
5. Check all oil and fluid reservoirs for proper levels. Fill to proper level with the oil or fluid approved for that system. If the oil reservoir on the slurry pump needs oil, fill until the oil is to the middle of the site glass (Figure 22).




WARNING

Using oils and fluids other than those approved and specified for each system may result in damage to the machine.

6. Inspect all moving components for damage or excessive wear. Repair or replace as needed.
7. Check braking system for damage or excessive wear. Repair or replace as needed.

Figure 22



Daily and Before Start of Season (Continued)

8. Check for solid, hard, or frozen substances on all moving parts. Remove substance to avoid damaging the machine.
9. Grease all points shown in Figures 23, 24, 25, and 26. Grease steering system according to "Steering System Lubrication" on Page 28.

After Starting Tractor


10. Check braking system for proper working operation.
11. Recheck all hoses and connections for leaks.
12. Check all lights for proper operation. Replace as needed.
13. Grease according operational requirements stated on the machine.



WARNING


Hydraulic and brake lines are under high pressure when tractor is running. Hydraulic fluids can become hot enough to cause serious burns. Use proper safety equipment when checking lines.

Figure 23




Grease points on both sides of Bull Pull hitch.

Figure 24




Grease points on both universal joints of the PTO shaft and on the shaft itself.

Figure 25



Two (2) grease points on each brake caliper.

Figure 26



Apply grease to both grease points on the tie rod and the kingpin grease point on each wheel. If the kingpin grease point is connected to a grease line, the grease point is located on the right side rear of the frame. If there is no kingpin grease point, the kingpin has a poly bushing and does not need any grease.

Every 40 Hours of Operation

1. Check all oil and fluid reservoirs for proper level. Fill as needed with correct oil or fluid.
2. Grease wheel bearings.
3. Torque lug nuts to 450 ft/lbs.

End of Season/Preparing for Storage

1. Change all oils and fluids with approved oils or fluids for that system. Fill to proper levels.
2. Grease all grease points.
3. Remove brass breather vent from bottom of steering cylinder and clean with solvent and compressed air. **DO NOT USE A WIRE BRUSH. THIS WILL DAMAGE THE VENT.**
4. Fill unit with water and operate the slurry pump to clean and flush it.
5. Open all drain plugs and doors to completely empty the machine.
6. Clean exterior and interior of unit thoroughly with a high pressure washer.
7. Apply a thick coat of grease on all cylinder rods before storing the unit.
8. Perform a complete lubrication of the unit.
9. Check for any oil or fluid leaks. Repair or replace as needed.
10. Store unit indoors.

	<h1 style="margin: 0;">CAUTION</h1>	<p>Thoroughly grease the steering system after pressure washing.</p>
--	-------------------------------------	---

Steering System Lubrication

There is one (1) grease fitting located on each kingpin. This fitting may be attached to a grease line placing the grease point on the right side rear of the frame. If the kingpin does not have a grease point, the kingpin then has a poly bushing which requires no grease.


There is one (1) grease fitting located on each end of the tie rod.

When greasing the kingpins, alternate between having the wheels straight one day, turned to the left, the next day, and then turned to the right the following day. This process ensures the grease is getting to all surfaces of the kingpin.

Apply grease daily to the grease points until fresh grease can be seen being pushed out from it. When conditions are dry and dusty, the kingpins and tie rod will require greasing more often.

Proper steering is dependent upon adequate greasing.

Figure 27



Hub Lubrication

The wheel bearings should be checked for wear and/or damage annually (Figure 27). Repack with grease before first use of the season. Use an EP2 grease. The inside of the hub is filled about 75% with grease to allow for heat expansion.


After the wheel bearings have been greased and placed back on the spindle, grease the washer and place on the spindle, then thread the castle nut. Tighten the nut using a wrench and rotate the hub in the opposite direction. The wrench should not drag against the hub when tightening. Tighten until the hub doesn't rotate freely using one hand. Back the nut off 1/2 turn, retighten the nut to the next slot and insert the locking pin (either a roll pin or a split cotter pin). The hub should rotate with one hand and, depending on the speed of rotation, the radial momentum will keep the hub rotating for a partial (1/8 to 1/4) turn after letting go of it. This should provide for the desired preload. If using a split cotter pin, bend the ends to secure the pin, then replace the hub cap gasket and hub cap.

Recheck the preload after 5 to 10 hours of use.

Hitch Lubrication

The Bull Pull hitch has two (2) grease fittings, one on each side (Figure 28). These should be greased daily under normal conditions.

Figure 28



PTO Shaft Lubrication Specifications

Lubricate all fittings (Figure 29) with a quality EP lithium grease meeting the NLGI #2 specifications and containing no more than 1% molybdenum disulfide (ex. Shell Super Duty or equivalent).

An EP lithium grease meeting the NLGI #2 specification and containing 3% molybdenum disulfide may be substituted for the telescoping members only.

Grease Recommendations

Location	Interval	Amount
Cross and Bearing	Daily	1 Pump ea.
Telescoping Shaft	Daily	4-8 Pumps

Replacement parts must be lubricated at time of assembly. Use the amount of grease listed above per location then follow lube recommendations above for lubricating intervals.

PTO Shaft Lubrication Specifications (Continued)

Lubrication

Lubricate with approved quality grease daily before starting work (Figure 29). Clean and grease the implement input driveline before each prolonged period of non-use.

Telescoping members must have lubrication to operate successfully regardless if a grease fitting is provided for that purpose. Telescoping members without fittings should be pulled apart and grease added manually to the inside of the outer telescoping member (Figure 30).

For any additional maintenance of the PTO shaft, please refer to the manufacturer's book that came with the PTO shaft.

Figure 29





Figure 30



DANGER

REPLACEMENT PARTS ARE NOT LUBRICATED! Proper lubrication must be done at time of assembly.

Suspension Height Adjustment

1. Position the tractor and machine on level ground.
2. Connect the two (2) yellow marked hoses to the tractor.
3. Completely lower the machine by disengaging the straight steer function and opening all ball valves. Once the machine is completely lowered, close all ball valves.
4. Engage the straight steer function.

Figure 31





Figure 32




Suspension Height Adjustment (Continued)

5. Open the Left Side Base End ball valve and the Rod End ball valve slowly and simultaneously (Figures 31 and 32). The cylinders can be filled by opening the valves a little. This will provide more control while filling the cylinders.
6. Raise the machine until the measurement of the exposed rod of the left side middle cylinder equals 7" (35.6 cm). This will leave the necessary average of 7" (17.8 cm) of exposed rod on all left side cylinders (Figure 43).
7. Close both valves.
8. Repeat for the right side middle cylinder.

The machine now has the suspension properly adjusted for operation.

Figure 33



Steering Axle Toe Adjustment

At the start of each season the steering axle toe should be checked for proper adjustment. Follow these steps to check and, if necessary, adjust the toe of the steering axle.

1. Lock the straight steer so the steering axle wheels are in line with the straight axle.
2. Raise the steering axle using a bottle jack or other device designed to safely lift the machine enough so both wheels of the steering axle are not touching the ground.
3. Before proceeding, place support items, such as jack stands with a sufficient weight rating, under the axle or the frame to support the machine. **The device lifting the machine should NOT be used as a support device. Place blocking or wheel chocks in front and back of each wheel of the straight axle to keep the machine from rolling.**




DANGER

DO NOT work under any part of this machine without proper support devices placed between the ground and the axles. Block the wheels to keep the machine from rolling.

Steering Axle Toe Adjustment (Continued)

4. Measure the wheel attached to the steering hydraulic cylinder first. From the vertical center of the wheel, measure from the inside front of the rim to the frame. Then measure from the inside rear of the rim to the frame (Figure 34).
5. The inside front measurement should be 1/16" (1.6 mm) shorter than the inside rear measurement.
6. If adjustment is needed, loosen the steering hydraulic cylinder's clevis clamp nut and bolt. The clevis is threaded onto the rod of the cylinder. Using a wrench on the cylinder rod, rotate the rod for proper toe adjustment (Figure 35). Do not tighten the clevis clamp nut and bolt yet.
7. Measure the other steering wheel. From the vertical center of the wheel, measure from the inside front of the rim to the frame. Then measure from the inside rear of the rim to the frame (Figure 34).

Figure 34




8. The inside front measurement should be 1/16" (1.6 mm) shorter than the inside rear measurement.
9. If adjustment is needed, loosen both jamb nuts on the tie rod (Figure 36). Rotate the direction needed to set the proper toe (Figure 46). Do not tighten the jamb nuts yet.
10. Measure both rims again for proper toe setting and readjust as necessary.
11. Tighten both jamb nuts on the tie rod and tighten the steering hydraulic cylinder's clevis clamp nut and bolt.
12. Repeat for the remaining steering axle.

Brake System

Adding Brake Fluid


1. Attach the jumper hose (Part #: 72182) between "A" port and "B" port (Figures 38 and 39).
2. Connect the 1/4" hydraulic brake hoses (Red) to the tractor.
3. Open ball valve on jumper hose (Figure 40).
4. Apply and hold pressure to braking system from tractor hydraulics.
5. Relieve all pressure from the 1/4" hydraulic brake hoses (Red).

Figure 35




Clamp Nut and Bolt

Figure 36



Tie Rod Jamb Nuts

Figure 37



Adjust Toe Out

Adjust Toe In

Brake System (Continued)

6. Close ball valve on jumper hose (Figure 41).
7. Remove jumper hose from "A" port and "B" port.
8. Apply and hold pressure to braking system.
9. Open bleeder screw on any brake caliper to adjust the brake master cylinder (Figure 42).
10. Allow the pressure releasing spring on the brake master cylinder to compress to 14" (35.6 cm) (Figure 43).

Figure 38





Figure 39




Bleeding the Brake System

1. Attach the jumper hose (Part #: 72182) between "A" port and "B" port (Figures 38 and 39).
2. Connect the 1/4" hydraulic brake hoses (Red) to the tractor.


Braking System (Continued)

Figure 40



To open the ball valve on the Bleeder Hose, rotate the handle so that it is inline with the hose.

Figure 41



To close the ball valve on the Bleeder Hose, rotate the handle so that it is perpendicular with the hose.

Figure 42





Figure 43




Braking System (Continued)

3. Apply and hold pressure to braking system from tractor hydraulics.
4. Open ball valve on jumper hose (Figure 40).
5. Loosen bleeder screw on brake caliper closest to the brake master cylinder first (Figure 42).
6. After air bubbles have stopped, tighten bleeder screw.
7. Repeat Steps 5 and 6 until all brake calipers have been bled.
8. Relieve all pressure from the 1/4" hydraulic brake hoses (Red).
9. Close ball valve on jumper hose (Figure 41).
10. Remove jumper hose from "A" port and "B" port.
11. Apply and hold pressure to braking system.
12. Open bleeder screw on any brake caliper to adjust the brake master cylinder (Figure 42).
13. Allow the pressure releasing spring on the brake master cylinder to compress to 14" (35.6 cm) (Figure 43).

Figure 44 shows the schematic for the Brake System.

Figure 44



The logo for BALZER, featuring the word in a bold, italicized, sans-serif font with a white outline and a grey drop shadow. The logo is positioned on a green diagonal band that runs from the top left towards the bottom right.

BALZER

Troubleshooting

Steering Not Working Correctly

1. Make sure the steering hydraulic lever is in the "FLOAT" position.
2. Check the hydraulic connections to the tractor. The YELLOW coded hoses should be connected to the right side of the tractor's hydraulic bank. The hose with one (1) stripe should be connected to the RETURN port and the hose with two (2) stripes should be connected to the PRESSURE port.
3. Grease the kingpins (if equipped with grease points) and the tie rod. Apply grease to the kingpins with the wheels straight and also with the wheels fully extended to each turning position. The kingpins and tie rod must be greased daily for proper steering system operation.
4. If the system is still not steering properly, call Balzer's Service Department at 1-800-795-8551 Ext. 134 (or press 0 for the operator).

Backing Up and Steering Not Locked Straight

1. Make sure the steering hydraulic lever is NOT in the "FLOAT" position.
2. Check the hydraulic connections to the tractor.
3. If the system is still not locking the steering wheels straight, call Balzer's Service Department at 1-800-795-8551 Ext. 134 (or press 0 for the operator).

Hydraulic Controls Not Working Properly

1. Check the hydraulic connections to the tractor:

A. RED marked hose	Brakes
B. YELLOW marked hose	Steering System
C. GREEN marked hose	3-Way Valve or T-Valve
D. ORANGE marked hose	Down Pressure Block
E. BLUE marked hose	Hydraulic Motor
F. BLUE/GREEN marked hose	Hydraulic Motor Zero Return
2. Check the tractor's hydraulic fluid levels.
3. Check the hydraulic system for leaks or hose line damage.
4. Attach the tractor to a different implement to identify if the problem is with the tractor or the implement.
5. If the problem is with the tractor, contact your local farm equipment service center.
6. If the problem is with the implement, call Balzer's Service Department at 1-800-795-8551 Ext. 134 (or press 0 for the operator).

Brakes Not Working Properly

1. Apply brakes.
2. Measure the compression of the pressure release spring.
 1. If the pressure release spring is compressed to 8" (20.3 cm) or less, hydraulic fluid must be added to the braking system (See "Brake System" on Page 32).

PTO Not Working

1. Check that the PTO drive lever on the tractor is engaged.
2. Disengage the PTO, shut off the tractor, and remove the key.
3. Check that the PTO is connected to the tractor.
4. Check the PTO shaft's shear bolt. If the shear bolt is broken, damaged, or missing, replace and attempt PTO operation again.
5. Disconnect the PTO from the tractor and engage the PTO drive on the tractor. Check to see that the tractor's PTO shaft is turning. If the tractor's PTO shaft is not turning, contact your local farm equipment service center.
6. For additional troubleshooting of the PTO shaft, see the manufacturer's book that came with the PTO shaft.
7. If PTO is still not working, call Balzer's Service Department at 1-800-795-8551 Ext. 134 (or press 0 for the operator).

Slurry Pump Not Working



1. Check if tank is empty.
2. PTO driven:
 - A. Check that the PTO shaft is connected to the tractor.
 - B. Check the PTO shear bolts and replace if broken.
3. Hydraulic Motor driven:
 - A. Check that the hydraulic lever controlling the hydraulic motor is engaged.
 - B. Check hydraulic hoses for proper connection to tractor.
 - C. Check hydraulic hoses for leaks.
 - D. Check the tractor's hydraulic fluid levels.
4. Check if the gate valves are open or closed.
5. If the pump is still not working, call Balzer's Service Department at 1-800-795-8551 Ext. 134 (or press 0 for the operator),

Rite Rate Flow System

Raven SCS660 NVM Not Working

1. Check to see if the Raven SCS660 Controller is turned on.
2. If the Raven SCS660 Controller is not turning on, turn off unit and check fuse on back of the controller (Figure 45). If fuse is blown, replace with a 15 AMP 32V Glass Tube fuse.
3. If the 15 AMP fuse is not blown, check the 20 AMP Blade Fuse that is located inline with the Red wire on the Raven

Figure 45



- SCS660 Console Cable attached to a key switched 12 VDC power source.
4. If the 20 AMP fuse is not blown, check the electrical connections:
 - A. Check that the Red wire connected to a key switched 12 VDC power source.
 - B. Check that the key switched 12 VDC power source is receiving power when the tractor key is in the operate/run position. If it is not receiving power, contact your local farm equipment service center.
 - C. Check that the White wire is connected to a good tractor grounding point.
 5. If both fuses are blown, there may be an issue with the tractor's electrical system. Contact your local farm equipment service center.

Rite Rate Flow System (Continued)

- Was the tractor jump started, welded on, or connected to a battery charger and the Raven SCS660 NVM power connections still connected? If yes, the Raven SCS660 NVM may have received some internal electronic damage. Contact Balzer's Service Department at 1-800-795-8551 Ext. 134 (or press 0 for the operator).

Raven SCS660 NVM Not Controlling Flow Properly

- Check the Raven SCS660 NVM programming. If the programming is not correct, see "Rite Rate Flow System Programming".
- If the programming is correct, check all connections between the Raven SCS660 NVM Controller and the
 - Krohne Optiflux 4100C
 - Raven 660 PWM Boost Box and down pressure block
 - Sky Trak GPS
- Check if the Sky Trak GPS has an unobstructed view of the sky and check GPS on another GPS capable device (a GPS enabled highway navigation system, such as Garmin or TomTom, or a cellular telephone with GPS capabilities) to see if that device is able to obtain a GPS signal. GPS systems require communication with at least four GPS satellites.
- Check the 1 AMP Blade Fuse that is inline with the Power Cable connected to the Krohne Flow Meter.
- If the 1 AMP fuse is not blown, check for voltage at the fuse. If no voltage is present, recheck all connections between the flow meter and the Raven SCS660 Controller.
- Check that the gate valves are open when the system is operating.
- Check that the pump is operating properly.
- If the flow is still not being properly controlled, call Balzer's Service Department at 1-800-795-8551 Ext. 134 (or press 0 for the operator).

Rite Rate Flow System Programming

When programming data into console, press the desired data key, press enter, press the numbers, then press enter to accept.

Example: To program the Valve Cal

- Press Valve Cal 
- Press Enter 
- Enter the numeric value (IE: 43 -  )
- Press Enter 

Initial Programming Steps:

- Turn Power on (if the display doesn't show **US VOLUME**, turn off the controller, press and hold  while turning the controller on.)
- Press  to accept **US - VOLUME**
- Press  until the display shows to **SP2 - RADAR**, then press 
- Press  to select **LIQUID SPRAYER**
- Press  until the display shows **C-PC-PWM CLOSE VALVE**, then press 

To complete the rest of the programming of the monitor, use the following initial settings:

- Press Boom Cal   = 150  (this is the width of the plow/injector toolbar in inches)
- Press the Up Arrow  to check the remaining Booms. The value for the remaining booms should be 0.

Rite Rate Flow System Programming (Continued)

8. Press Speed Cal ENTER = 598 ENTER (this is the value for the Sky Trak GPS)
9. Press Meter Cal ENTER = 50 ENTER
10. Press Valve Cal ENTER = 43 ENTER
11. Press Rate 1 Cal ENTER = 2500.0 ENTER (be sure to remember the 0 following the decimal point)
12. Press Rate 2 Cal ENTER = 3000.0 ENTER

Rate 1 and Rate 2 can have any desired application flow rate, however, both need to have a flow rate entered to complete setup. These rates can be changed through this console after the setup is completed.

Record your settings for Boom Width, Rate 1, and Rate 2 for future reference should the controller need to be reprogrammed.

Boom Width (in Inches)	Rate 1	Rate 2

If the controller needs to be reprogrammed, press and hold while turning the power on then start with Step 2 above.

For additional information on the Raven SCS660 NVM Controller, see the manufacturer's manual that came with the unit.

For additional information on the Sky Trak GPS, see the manufacturer's manual that came with the unit.


For additional information on the Krohne Optiflux Flow Meter and Signal Converter, see the manufacturer's manuals that came with the unit.

Rite Rate Console Cable Preparation

The Console cable should come prepared for immediate use. If needing to prepare the Console Cable, use the following steps.

1. Open wire loom and pull the Orange wire back towards the 16-pin plug until it is about halfway between the 16-pin plug and where the Red and White wires exit the Console Cable.
2. Pull the Blue wire out enough to make a small loop.
3. Cut the Orange wire and the Blue wire (Figure 46).

Figure 46




4. Push the Blue wire leading to the 16-pin plug back into the wire loom (this wire is not needed).

Rite Rate Console Cable Preparation (Continued)

5. Strip about 3/8" to 1/2" of both cut Orange wire ends and the remaining Blue wire end.
6. Assemble the wires as shown in Figure 47. Use a heat shrink solder connector with a heat gun (this will solder the wires together and shrink seal the ends) or twist the exposed wires together and solder with a soldering iron. **DO NOT** use crimp connectors for this connection as they can work themselves loose and create an intermittent connection.
7. If using a soldering iron, after the solder has cooled, use electrical tape to wrap the wires from about 1" above the joint to about 1" below the joint.
8. Push the soldered and sealed joint back into the wire loom leaving only the Orange wire tail exposed.

Figure 47




Rite Rate Wiring Installation

Figure 48 shows the Rite Rate system wiring installation and connections.

1. Connect the 16-pin plug on the Console Cable to the 16-pin receptacle on the back of the Raven SCS660 Controller.
2. Connect the 3-pin plug on the Sky Trak GPS to the 3-pin receptacle on the back of the Raven SCS660 Controller.
3. Connect the Orange wire of the Console Cable to the Blue wire of the Sky Trak GPS.
4. Place the Sky Trak GPS as high as possible on the tractor in a space that will allow the Sky Trak GPS unrestricted exposure to the sky. The Sky Trak GPS has a magnetic base for placement on a metal surface for mounting.
5. Connect both connectors of the Console Cable to the Flow Control Cable.
6. Connect a White wire of the Flow Control Cable to the White wire of the Raven 660 Boost Box.
7. Connect the Yellow/Green wire connector of the Flow Control Cable to the Yellow/Green wire connector of the Raven 660 Boost Box.
8. Connect the Black wire of the Flow Control Cable to the Red wire of the Raven 660 Boost Box.
9. Connect the wires from the Raven 660 Boost Box to the Down Pressure Block.
10. Connect the Blue wire of the Flow Control Cable to the Red wire of the Power Cable to the Flow Meter.
11. Connect a White wire of the Flow Control Cable to the Black wire of the Power Cable to the Flow Meter.
12. Connect the 3-pin connector of the Flow Control Cable to the 3-pin connector of the Extension Cable.
13. The remaining White wire and the Brown wire of the Flow Control Cable are not used. Wrap the ends with electrical tape to protect the connectors.
14. Connect the 4-pin connector of the Power Cable to the 4-pin connector of the Krohne Flow Meter.
15. Connect the 3-pin connector of the Extension Cable to the 3-pin connector of the Krohne Flow Meter.
16. Return to the Console Cable and connect the White wire from the smaller wire loom to the Tractor Ground.
17. Connect the Red wire from the smaller wire loom to a Key Switched +12 VDC power source.

Rite Rate Wiring Installation (Continued)

Figure 48



The logo for BALZER is rendered in a bold, italicized, sans-serif font. The letters are black with a white outline and a grey drop shadow, giving it a three-dimensional appearance. It is positioned on a green diagonal band that runs from the top left towards the bottom right.

Notes

Date

Notes

Date

Notes



Magnum Slurry Tank (Tridem)

User Manual

UM-MST-2



Balzer Incorporated reserves the right to make changes to their product and/or this manual to improve reliability, function, design, or safety without further notice. Balzer Incorporated is under no obligation, implied or otherwise, to upgrade, modify, or otherwise make changes to product manufactured prior to any design change.

Balzer Incorporated does not assume any liability arising out of the application or use of any product and neither does it convey any license under its patent rights. Balzer Incorporated does not assume any liability arising out of the use of their product for applications outside those for which it is expressly designed for.

© 2015 Balzer Inc. All Rights Reserved